



TECHNICAL SERVICE MANUAL

ABRASIVE LIQUID PUMPS
SERIES - 4625
SIZES F - FH

SECTION TSM 410.1
PAGE 1 OF 5
ISSUE B

CONTENTS

Introduction	1
Special Information	2
Maintenance	2
Disassembly	3
Assembly	4

INTRODUCTION

The illustrations used in this manual are for identification purposes only and should not be used for ordering parts. Secure a parts list from the factory or a Viking representative. Always give complete name of part, part number and material with the model and serial number of the pump when ordering repair parts.

UNMOUNTED PUMP AND UNIT MODEL NUMBERS

UNMOUNTED PUMP	UNITS
F4625	Units are designated by the un-mounted pump model numbers followed by a letter(s) indicating drive style.
FH4625	V = V-Belt D = Direct Connected



FIGURE 1
SERIES 4625 PUMP
"F" AND "FH" SIZES

This manual deals exclusively with the F and FH 4625 pumps. Figure 1 describes the overall appearance of the pumps in this manual.

SPECIAL INFORMATION

DANGER

BEFORE OPENING ANY VIKING PUMP LIQUID CHAMBER (PUMPING CHAMBER, RESERVOIR, RELIEF VALVE ADJUSTING CAP FITTING ETC.) BE SURE:

1. THAT ANY PRESSURE IN CHAMBER HAS BEEN COMPLETELY VENTED THROUGH SUCTION OR DISCHARGE LINES OR OTHER APPROPRIATE OPENINGS OR CONNECTIONS.
2. THAT THE DRIVING MEANS (MOTOR, TURBINE, ENGINE, ETC.) HAS BEEN "LOCKED OUT" OR MADE NON-OPERATIONAL SO THAT IT CANNOT BE STARTED WHILE WORK IS BEING DONE ON PUMP.
3. THAT YOU KNOW WHAT LIQUID THE PUMP HAS BEEN HANDLING AND THE PRECAUTIONS NECESSARY TO SAFELY HANDLE THE LIQUID. OBTAIN A MATERIAL SAFETY DATA SHEET (MSDS) FOR THE LIQUID TO BE SURE THESE PRECAUTIONS ARE UNDERSTOOD.

FAILURE TO FOLLOW ABOVE LISTED PRECAUTIONARY MEASURES MAY RESULT IN SERIOUS INJURY OR DEATH.

ROTATION: Viking pumps operate equally well in a clockwise or counterclockwise rotation. Shaft rotation determines which port is suction and which is discharge. Port in area where pumping elements (gear teeth) come out of mesh is suction port.



VIKING PUMP INC. •
A Unit of IDEX Corporation •

SPECIAL INFORMATION

PRESSURE RELIEF VALVES:

1. Viking pumps are positive placement pumps and must be provided with some sort of pressure protection. This may be a relief valve mounted directly on the pump, an inline pressure relief valve, a torque limiting device or a rupture disk.
2. There are relief valve options available on those pump models designed to accept a relief valve. Options may include a return to tank relief valve and a jacketed relief valve. Pumps equipped with a jacketed head plate are generally not available with a relief valve.
3. If pump rotation is to be reversed during operation, pressure protection must be provided on *both* sides of pump.
4. Relief valve adjusting screw cap must always point towards suction side of pump.
5. Pressure relief valves cannot be used to control pump flow or regulate discharge pressure.

SPECIAL MECHANICAL SALES:

Extra care should be taken in repair of these pumps. Be sure to read and follow all special instructions supplied with your pump.

MAINTENANCE

Model 4625 pumps are designed for long, trouble free life under a wide variety of application conditions with a minimum of maintenance, however, the following should be considered.

1. **LUBRICATION** - External lubrication must be applied slowly with a handgun to all lubrication fittings every 500 hours of operation with multi-purpose grease, NLGI # 2. Do not over-grease. Applications involving very high or low temperatures will require other types of lubrication. Refer to **Engineering Service Bulleting ESB-515**. Consult factory with specific lubrication questions.
2. **END CLEARANCE ADJUSTMENT** - After long term operation it is sometimes possible to improve the performance of the pump, without major repair, through adjustment of end clearance of the pump. Refer to instructions under Reassembly of the pump for information regarding this procedure.
3. **CLEANING THE PUMP** - It is good practice to keep the pump as clean as possible. This will facilitate inspection, adjustment and repair work.
4. **STORAGE** - If the pump is to be stored or not used for any appreciable length of time it should be drained and a light coat of lubricating and preservative oil should be applied to the internal parts.

SPECIAL INFORMATION

SUGGESTED REPAIR TOOLS: The following tools must be available to properly repair Series 4625 pumps. These tools are in addition to standard mechanics' tools such as open end wrenches, pliers, screwdrivers etc. Most of the items can be obtained from an industrial supply house.

1. Soft Headed Hammer
2. Allen Wrenches (some mechanical seals and set collars)
3. Bearing locknut spanner wrench
(Source: #471 J.H. Williams & Co. or equal)
4. Arbor Press

DISASSEMBLY

DANGER

BEFORE OPENING ANY VIKING PUMP LIQUID CHAMBER (PUMPING CHAMBER, RESERVOIR, RELIEF VALVE ADJUSTING CAP FITTING ETC.) BE SURE:

1. THAT ANY PRESSURE IN CHAMBER HAS BEEN COMPLETELY VENTED THROUGH SUCTION OR DISCHARGE LINES OR OTHER APPROPRIATE OPENINGS OR CONNECTIONS.
2. THAT THE DRIVING MEANS (MOTOR, TURBINE, ENGINE, ETC.) HAS BEEN "LOCKED OUT" OR MADE NON-OPERATIONAL SO THAT IT CANNOT BE STARTED WHILE WORK IS BEING DONE ON PUMP.
3. THAT YOU KNOW WHAT LIQUID THE PUMP HAS BEEN HANDLING AND THE PRECAUTIONS NECESSARY TO SAFELY HANDLE THE LIQUID. OBTAIN A MATERIAL SAFETY DATA SHEET (MSDS) FOR THE LIQUID TO BE SURE THESE PRECAUTIONS ARE UNDERSTOOD.

FAILURE TO FOLLOW ABOVE LISTED PRECAUTIONARY MEASURES MAY RESULT IN SERIOUS INJURY OR DEATH.

DISASSEMBLY

Review Fig. 2 and 3 before proceeding with disassembly.

1. Remove Locknut and Lockwasher from drive end of shaft. Be sure to bend up tab of lockwasher before attempting to remove locknut.
2. Remove Packing Nut.
3. Remove the Capscrews and the Head from the pump. It may be necessary to tap the drive end of shaft to loosen head. **DO NOT PRY** the head from the casing as this may damage the gasket surface.
4. Slide Rotor and Shaft from Casing. It may be necessary to tap lightly on drive end of shaft in order to slide shaft through ball bearing bore. The rotary member of mechanical seal will stay with the Rotor & Shaft when removed.

5. Remove Ball Bearing and Bearing Retainer Washer from Casing Bore.
6. Remove Rotary Member of Mechanical Seal from Rotor Shaft. Carefully inspect ceramic face for wear and the o-ring in I.D. of rotary member for cuts or other signs of damage. Replace if necessary.
7. Remove Seal Seat from casing. Use a simple tool such as a wire or old screwdriver with a short hook bent on the end. Slide this hook into crevice between seal seat and casing bushing and pull seat out head end of casing. Inspect face for wear. It is recommended that a new mechanical seal be used every time a pump is disassembled.




FIGURE 2 EXPLODED VIEW SERIES 4625

ITEM	NAME OF PART	ITEM	NAME OF PART	ITEM	NAME OF PART
1	Locknut	6	Grease Fitting	11	Idler
2	Lockwasher	8	Casing	12	Head Gaskets
3	Packing Nut	9	Casing Bushing	13	Idler Pin
4	Ball Bearing	10	Mechanical Seal	14	Head
5	Washer, Brg. Retainer	11	Rotor and Shaft	15	Capscrews




FIGURE 3 - SECTIONAL VIEW OF SERIES 4625

ASSEMBLY

All parts should be examined for wear before the pump is put together. When making major repairs, such as replacing a rotor and shaft, it is advisable to install a new casing bushing.

INSTALLING CASING BUSHING - The casing bushing can be replaced in the following manner: Insert a bar approximately .9375" diameter and at least 3.5" long in the seal end of casing and press the bushing out of the casing. When installing a new bushing an arbor press should be used. Coat the bushing with light lube oil and press the bushing into bore from head end. The bushing should be positioned so that the face of bushing is .0625" below the surface of step machined for seal seat, see **Figure 4**.

1. Clean all parts thoroughly.
2. Coat the complete seal seat with light oil and install it into casing. Make sure that the pins on backside of seat go into the holes provided for them in casing. (Putting a light pencil line in bore of seal seat in line with pins will help keep pins in proper alignment with holes).
3. Coat rotor shaft with light oil. Slide mechanical seal wavy spring washer onto shaft. Coat bore and lapped face of rotary member of mechanical seal with light oil and slide onto rotor shaft. Position drive pins in two holes in back of rotor. Slide rotor into pump casing.

4. Place nine 0.002 inch (.018 inch total) gaskets on head. Place idler on head and install into pump casing. Install three capscrews (every other one), tighten finger tight then loosen one turn.

5. Slide bearing retainer washer onto drive end of rotor shaft and position against shoulder on shaft. Slide ball bearing onto shaft and into bore of casing as far as it will go easily. At this point slide a sleeve over drive end of shaft and up against inner race of bearing and press bearing into place.

6. Install lockwasher & locknut. Tighten locknut to 15-20 ft.-lbs. Torque (F-FH) . Tighten nut securely and bend tang of lockwasher into slot of locknut.

NOTE: Hold rotor shaft from turning while tightening locknut by fastening a wrench on flat of shaft.

7. Install packing nut and tighten securely.

8. Tighten the three capscrews. Add or remove gaskets (using either .001 or .003) until the rotor drags slightly on the head; then add two .001 thick gaskets. End clearance is now set properly. Put in remaining three capscrews and double check to be sure rotor is free to turn.

ASSEMBLY

NOTE: If the capacity of pump has decreased after long term operation it is sometimes possible to increase capacity again by removing (1) or more head gaskets. If this is done be sure to turn pump over by hand before starting.

DO NOT OPERATE PUMP "DRY"; make sure there is a supply of liquid in the suction line prior to start-up.




FIGURE 4

DANGER

BEFORE STARTING PUMP, BE SURE ALL DRIVE EQUIPMENT GUARDS ARE IN PLACE.

FAILURE TO PROPERLY MOUNT GUARDS MAY RESULT IN SERIOUS INJURY OR DEATH.

WARRANTY

Viking warrants all products manufactured by it to be free from defects in workmanship or material for a period of one (1) year from date of startup, provided that in no event shall this warranty extend more than eighteen (18) months from the date of shipment from Viking. If, during said warranty period, any products sold by Viking prove to be defective in workmanship or material under normal use and service, and if such products are returned to Viking's factory at Cedar Falls, Iowa, transportation charges prepaid, and if the products are found by Viking to be defective in workmanship or material, they will be replaced or repaired free of charge, FOB. Cedar Falls, Iowa.

Viking assumes no liability for consequential damages of any kind and the purchaser by acceptance of delivery assumes all liability for the consequences of the use or misuse of Viking products by the purchaser, his employees or others. Viking will assume no field expense for service or parts unless authorized by it in advance.

Equipment and accessories purchased by Viking from outside sources, which are incorporated into any Viking product, are warranted only to the extent of and by the original manufacturer's warranty or guarantee, if any.

THIS IS VIKING'S SOLE WARRANTY AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, WHICH ARE HEREBY EXCLUDED, INCLUDING IN PARTICULAR ALL WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. No officer or employee of IDEX Corporation or Viking Pump, Inc. is authorized to alter this warranty.



TECHNICAL SERVICE MANUAL

ABRASIVE LIQUID HEAVY-DUTY BRACKET MOUNTED PUMPS

SERIES 4625

SIZES H-M

SECTION TSM 410.2
PAGE 1 OF 9
ISSUE B

CONTENTS

Introduction	1
Special Information	2
Maintenance	2
Disassembly	4
Assembly	5
Thrust Bearing Adjustment	7
Pressure Relief Valve Instructions	8

INTRODUCTION

The illustrations used in this manual are for identification purposes only and cannot be used for ordering parts. Obtain a parts list from the factory or a Viking representative. Always give complete name of part, part number and material with model number and serial number of pump when ordering repair parts. The unmounted pump or pump unit model number and serial number are on the nameplate.

In the Viking model number system, basic size letters are combined with series number 4625 indicating both unmounted or mounted pump unit.



FIGURE 1
SIZES H AND HL



FIGURE 2
SIZES K, KK AND L



FIGURE 3
SIZES LQ AND LL



FIGURE 4
SIZES Q AND M

SPECIAL INFORMATION

DANGER

BEFORE OPENING ANY VIKING PUMP LIQUID CHAMBER (PUMPING CHAMBER, RESERVOIR, RELIEF VALVE ADJUSTING CAP FITTING ETC.) BE SURE:

1. THAT ANY PRESSURE IN CHAMBER HAS BEEN COMPLETELY VENTED THROUGH SUCTION OR DISCHARGE LINES OR OTHER APPROPRIATE OPENINGS OR CONNECTIONS.
2. THAT THE DRIVING MEANS (MOTOR, TURBINE, ENGINE, ETC.) HAS BEEN "LOCKED OUT" OR MADE NON-OPERATIONAL SO THAT IT CANNOT BE STARTED WHILE WORK IS BEING DONE ON PUMP.
3. THAT YOU KNOW WHAT LIQUID THE PUMP HAS BEEN HANDLING AND THE PRECAUTIONS NECESSARY TO SAFELY HANDLE THE LIQUID. OBTAIN A MATERIAL SAFETY DATA SHEET (MSDS) FOR THE LIQUID TO BE SURE THESE PRECAUTIONS ARE UNDERSTOOD.

FAILURE TO FOLLOW ABOVE LISTED PRECAUTIONARY MEASURES MAY RESULT IN SERIOUS INJURY OR DEATH.

ROTATION: Viking pumps operate equally well in a clockwise or counter-clockwise rotation. Shaft rotation determines which port is suction and which is discharge. Port in area where pumping elements (gear teeth) come out of mesh is suction port.

PRESSURE RELIEF VALVES:

1. Viking pumps are positive placement pumps and must be provided with some sort of pressure protection. This may be a relief valve mounted directly on the pump, an inline pressure relief valve, a torque limiting device or a rupture disk.
2. There are relief valve options available on those pump models designed to accept a relief valve. Options may include a return to tank relief valve and a jacketed relief valve. Pumps equipped with a jacketed head plate are generally not available with a relief valve.
3. If pump rotation is to be reversed during operation, pressure protection must be provided on *both* sides of pump.
4. Relief valve adjusting screw cap must always point towards suction side of pump. If pump rotation is reversed, remove pressure relief valve and turn end for end. **Refer to Figures 1 and 2.**

5. Pressure relief valves cannot be used to control pump flow or regulate discharge pressure.

For additional information on pressure relief valves, **Refer to Technical Service Manual TSM000 and Engineering Service Bulletin ESB-31.**

SPECIAL MECHANICAL SEALS:

Extra care should be taken in repair of these pumps. Be sure to read and follow all special instructions supplied with your pump.

MAINTENANCE

Series 4625 pumps are designed for long, trouble-free service life under a wide variety of application conditions with a minimum of maintenance. The points listed below will help provide long service life.

LUBRICATION: External lubrication must be applied slowly with a handgun to all lubrication fittings every 500 hours of operation with multi-purpose grease, NLGI # 2. Do not over-grease. Applications involving very high or low temperatures will require other types of lubrication. **Refer to Engineering Service Bulletin ESB-515.** Consult factory with specific lubrication questions.

CLEANING PUMP: Keep pump as clean as possible. This will facilitate inspection; adjustment and repair work and help prevent overlooking a dirt covered grease fitting.

STORAGE: If pump is to be stored, or not used for six months or more, pump must be drained and a light coat of non-detergent SAE 30 weight oil must be applied to all internal pump parts. Lubricate fittings and apply grease to pump shaft extension. Viking suggests rotating pump shaft by hand one complete revolution every 30 days to circulate the oil.

SUGGESTED REPAIR TOOLS: The following tools must be available to properly repair Series 4625 pumps. These are in addition to standard mechanics' tools such as open end wrenches, pliers, screwdrivers etc. Most of the items can be obtained from an industrial supply house.

1. Soft Headed Hammer
2. Mechanical seal installation sleeve
2-751-002-900 for 1.125 inch seal; H & HL 4625
2-751-003-900 for 1.4375 inch seal; K & LL 4625
2-751-005-630 for 2.4375 inch seal; Q and M4625
3. Bearing locknut spanner wrench
(Source: #471 J.H. Williams & Co. or equal)
4. Spanner wrench, adjustable pin type for use on double end caps (Source #482 J.H. Williams & Co or equal)
5. Brass Bar
6. Arbor Press






FIGURE 5
CUTAWAY VIEW OF KK 4625 WITH CALLOUTS

EXPLODED VIEW FOR MODELS H4625, HL4625, K4625, KK4625, L4625, LQ4625 AND LL4625
(MODEL KK4625 SHOWN)



ITEM	NAME OF PART	ITEM	NAME OF PART	ITEM	NAME OF PART
1	Locknut	11	Pressure Relief Plug	21	Idler and Bushing
2	Lockwasher	12	Grease Fitting	22	Head Gasket
3	End Cap, (outer)	13	Bracket and Bushing	23	Idler Pin
4	Lip Seal for End Cap	14	Capscrew for Bracket	24	Head and Idler Pin
5	Bearing Spacer Collar, (outer)	15	Bracket Bushing	25	Capscrew for Head
6	Ball Bearing	16	Mechanical Seal	26	Relief Valve Gasket
7	Bearing Spacer Collar, (inner)	17	Bracket Gasket	27	Capscrew for Valve
8	Ring, Half Round (K-LL)	18	Casing	28	Internal Relief Valve
9	End Cap (inner)	19	Pipe Plug		
10	Lip Seal for Seal Chamber	20	Rotor and Shaft		

EXPLODED VIEW FOR MODELS Q4625 AND M4625 (M4625 SHOWN)



ITEM	NAME OF PART	ITEM	NAME OF PART	ITEM	NAME OF PART
1	Locknut	13	Bracket Bushing	25	Head Gasket
2	Lockwasher	14	Pipe Plug	26	Idler Pin Sleeve & Self Lock Pin
3	End Cap, (outer)	15	Mechanical Seal	27	Idler Pin Sleeve
4	Lip Seal for End Cap	16	Spring Washer (M only)	28	Head, Pin and Sleeve
5	Bearing Spacer Collar	17	Bracket Gasket	29	Stud for Head
6	Ball Bearing	18	Casing	30	Nut for Head
7	End Cap (inner)	19	Pipe Flange Gasket	31	Relief Valve Gasket
8	Lip Seal for Seal Chamber	20	Nut for Flanges	32	Capscrew for Valve
9	Pressure Relief Plug	21	Stud for Flanges	33	Internal Relief Valve
10	Grease Fitting	22	Pipe Plug		Flush Line not illustrated
11	Bracket and Bushing	23	Rotor and Shaft		
12	Capscrew for Bracket	24	Idler and Bushing		

DISASSEMBLY

DANGER

BEFORE OPENING ANY VIKING PUMP LIQUID CHAMBER (PUMPING CHAMBER, RESERVOIR, RELIEF VALVE ADJUSTING CAP FITTING ETC.) BE SURE:

1. THAT ANY PRESSURE IN CHAMBER HAS BEEN COMPLETELY VENTED THROUGH SUCTION OR DISCHARGE LINES OR OTHER APPROPRIATE OPENINGS OR CONNECTIONS.
2. THAT THE DRIVING MEANS (MOTOR, TURBINE, ENGINE, ETC.) HAS BEEN "LOCKED OUT" OR MADE NON-OPERATIONAL SO THAT IT CANNOT BE STARTED WHILE WORK IS BEING DONE ON PUMP.
3. THAT YOU KNOW WHAT LIQUID THE PUMP HAS BEEN HANDLING AND THE PRECAUTIONS NECESSARY TO SAFELY HANDLE THE LIQUID. OBTAIN A MATERIAL SAFETY DATA SHEET (MSDS) FOR THE LIQUID TO BE SURE THESE PRECAUTIONS ARE UNDERSTOOD.

FAILURE TO FOLLOW ABOVE LISTED PRECAUTIONARY MEASURES MAY RESULT IN SERIOUS INJURY OR DEATH.

1. Mark head and casing before disassembly to insure proper reassembly. The idler pin, which is offset in pump head, must be positioned toward and equal distance between port connections to allow for proper flow of liquid through pump.

Remove head from pump. **Do not allow idler to fall from idler pin.** Tilt top of head back when removing to prevent this. Avoid damaging head gasket. If pump is furnished with pressure relief valve, it need not be removed from head or disassembled at this point. Refer to **Pressure Relief Valve Instructions**, page 8.

If pump has jacketed head plate, it will separate from head when it is removed. The gasket between head and jacket head plate must be totally removed. Use new gasket when assembling pump.

2. Remove idler and bushing assembly.
3. Insert length of hardwood or brass through port opening between rotor teeth to keep shaft from turning. Bend up tang of lockwasher and with a spanner wrench remove locknut and lockwasher from shaft.
4. Tap shaft forward approximately 0.50 inch and remove pair of half round rings under inner bearing spacer collar. There is no pair of half round rings on H, HL, Q and M size pumps.
5. Carefully remove rotor and shaft to avoid damaging bracket bushing.
6. Remove rotary member of seal from shaft and stationary seal seat from bracket.




FIGURE 6

7. Loosen setscrews. Two for G, H and HL size pumps, four for all other sizes. With spanner wrench, remove both end caps and lip seals. Remove ball bearing and spacer collars. Refer to **Figure 6**, page 5.
8. Examine seal chamber lip seal and remove if it shows wear or damage. Lip seal must be removed if bracket bushing needs to be replaced.
9. Clean all parts thoroughly and examine for wear or damage. Check lip seals, ball bearing, bushing and idler pin and replace if necessary. It is often possible to reuse the idler pin rather than replace it. Note position of the worn area at least 0.33 turn from previous position. Check all other parts for nicks, burrs, excessive wear and replace if necessary.
10. Casing can be checked for wear or damage while mounted on bracket.
11. Check flush line to be sure it is open. A long wire may be used to do this. Clean or replace if it is clogged.

ASSEMBLY

Mechanical Seal – (Silicon Carbide with Viton Elastomer)

The seal used in this pump is simple to install and good performance will result if care is taken during installation. Seal faces are made from silicon carbide which is extremely hard and brittle. Do not drop these parts or otherwise mishandle as the faces can chip easily.

The principle of the mechanical seal is contact between the rotary and stationary members. These parts are lapped to a high finish and their sealing effectiveness depends on complete contact.

1. Install bracket bushing. If bracket bushing has a lubrication groove, install bushing with groove at 6.00 o'clock position in bracket.
2. Install lip seal in bracket. Refer to Figure 7.




FIGURE 7

Prior to installing rotating portion of mechanical seal, prepare and organize rotor shaft, head and idler assemblies and appropriate gaskets for quick assembly.

Never touch sealing faces with anything except clean hands or clean cloth. Minute particles can scratch the seal faces and cause leakage.

3. Coat idler pin with non-detergent SAE 30 weight oil and place idler and bushing on idler pin in head.
4. Clean rotor hub and bracket seal housing bore. Make sure both are free from dirt and grit. Coat outer diameter of seal seat and inner diameter of seal housing bore with non-detergent SAE 30 weight oil.
5. Install seal seat in seal housing bore, Refer to Figure 8. Make sure drive pins are located in slots in bracket bushing.
6. Place tapered installation sleeve on shaft, Refer to Figure 9. Sleeve is furnished with H, HL, K, KK, L, LQ and LL size replacement mechanical seals. Sleeve for Q and M size pumps may be purchased from Viking Pump at additional cost. Coat rotor shaft, tapered installation sleeve and inner diameter of mechanical seal rotary member with a generous amount of non-detergent SAE 30 weight oil. Petrolatum may be used but grease is not recommended.

NOTE: Teflon fitted seals come with installation sleeve inside the rotary member. **DO NOT** remove this sleeve. Coat shaft with oil and proceed with step 7.

7. Place seal spring on shaft against rotor hub. Refer to Figure 10.

NOTE: Model M-4625 uses a seal spring washer. Install washer against rotor hub and then install seal spring.




FIGURE 8




FIGURE 9




FIGURE 10

8. Slide rotary member, lapped contact surface facing away from spring, over installation sleeve on shaft until it is against spring. Slot in the seal must line up with drive pin shaft.

NOTE: For teflon seals the rotary member and installation sleeve go on together.

Do not compress spring.

Flush sealing faces of both rotary member and stationary member with non-detergent SAE 30 weight oil just before installing rotor and shaft.

9. Coat rotor shaft with non-detergent SAE 30 weight oil. Start end of shaft in bracket bushing and turn from right to left, slowly pushing until ends of rotor teeth are just below face of casing.

Leave rotor in this position. Withdrawl of the rotor and shaft, may displace seal rotating face and result in damage to seal.

10. Using a .010 to .015 inch head gasket, install head and idler assembly on pump. Pump head and casing were marked before disassembly to insure proper reassembly. If not, be sure idler pin, which is offset in pump head, is positioned toward and equal distance between port connections to allow for proper flow of liquid through pump.

Tighten head capscrews evenly.

Remove tapered installation sleeve from the shaft.

11. If pump is equipped with jacketed head plate, install at this time along with new gasket.

If pump was equipped with a relief valve and was removed during disassembly, install on head with new gaskets. Relief valve adjusting screw cap must always point toward suction port. **Refer to Figures 1 & 2** on Page 1. For relief valve repair or adjustments, see **Pressure Relief Valve Instructions**, Page 8.

12. Slide inner spacer collar over shaft with recessed end facing rotor. H, HL, Q and M size bearing spacer collars are not recessed.

Place pair of half round rings on shaft and slide inner bearing spacer collar over half round rings to lock them in place. There is no pair of half round rings on H, HL, Q and M size pumps. **Refer to Figure 6**, page 5.

13. Press lip seal, lip facing end of shaft, in inner end cap and insert end cap through shaft end of bracket. Turn end cap clockwise, looking at shaft end, until it engages threads. End cap spanner wrench holes must be facing rotor. Turn end cap with spanner wrench until it projects slightly from opening on side of bracket. End cap must not be turned so far that lip seal drops off end of spacer collar on shaft or end cap becomes disengaged from threads. **Refer to Figure 6**, page 5.

If this happens, remove inner spacer collar, half round rings and end cap and start over at Step 12.

14. Pack ball bearing with multi-purpose grease, NLGI #2. Place on shaft and push or gently drive in place in bracket.

15. Press lip seal, lip facing end of shaft, in outer end cap and insert end cap in bracket. Turn end cap in bracket until it is tight against bearing. **Refer to Figure 6**, page 5.

16. Put lockwasher and locknut on shaft. Insert length of hardwood or brass through port opening between rotor teeth to keep shaft from turning.

Tighten locknut to 50-70 ft.- lbs. Torque (H-HL) or 100-130 ft. - lbs. Torque (K-LL) or 170-190 ft. - lbs. Torque (Q-M). Bend one tang of lockwasher into slot of locknut. If tang does not line up with slot, tighten locknut until it does. Failure to tighten locknut or engage lockwasher tang could result in early bearing failure and cause damage to rest of pump.

Remove length of hardwood or brass from port opening.

Adjust pump end clearance. **Refer to Thrust Bearing Adjustment**, page 7.

Lubricate grease fitting over seal chamber with petroleum jelly, petrolatum (Vaseline) or other similar low melting point lubricant. Lubricate all other grease fittings with multi-purpose grease, NLGI #2.

DANGER

BEFORE STARTING PUMP, BE SURE ALL DRIVE EQUIPMENT GUARDS ARE IN PLACE.

FAILURE TO PROPERLY MOUNT GUARDS MAY RESULT IN SERIOUS INJURY OR DEATH.

THRUST BEARING ADJUSTMENT

1. Loosen setscrews over outer and inner end caps. Two for H and HL size pumps, four for all other sizes.
2. Turn inner end cap clockwise, viewed from shaft end, until it projects slightly from bracket exposing approximately three threads.
3. Turn outer end cap clockwise until rotor is tight against head and rotor shaft cannot be turned.
4. Make a reference mark on bracket end, opposite a notch on outer end cap. Back off outer end cap required number of notches. **Refer to Figure 11**.
5. End clearances set per Step 4 are adequate for viscosities up to 750 SSU (SEA20 lube oil at room temperature). Higher viscosity liquids require additional end clearances.

As a general guideline, for viscosities between 750 and 7500 SSU (heavier lube oils) double the amount of end clearance indicated in Step 4; for viscosities between 7500 and 75,000 SSU (e.g., resins) triple the amount.

For specific recommendations for end clearances for viscosity or for operating temperatures above 225°F, check with your Viking representative or consult the factory.

6. Tighten inner end cap with a spanner wrench. Tap spanner wrench lightly but **DO NOT OVER TIGHTEN** as it will only damage the threads.
7. Tighten all setscrews that hold inner and outer end caps to prevent their turning in bracket.
8. Rotor and shaft should turn smoothly by hand one complete revolution. If rotor and shaft doesn't turn smoothly, go back and repeat Thrust Bearing Adjustment Steps 1 through 8.

Pump Size	TURN OUTER END CAP C.C.W.		
	No. of Notches	Length on O.D.	Total End Clearance
H-HL	3	0.50	.003
K-LL	5	2.313	.005
Q-M	5	2.25	.010

FIGURE 11

PRESSURE RELIEF VALVE INSTRUCTIONS




FIGURE 12
SIZE H AND HL




FIGURE 13
SIZE K. KK. L. LQ AND LL




FIGURE 14
SIZE Q AND M

LIST OF PARTS									
1. Valve Cap	6. Valve Body								
2. Adjusting Screw	7. Valve Spring								
3. Lock Nut	8. Poppet								
4. Spring Guide	9. Cap Gasket								
5. Bonnet	10. Bonnet Gasket								

DISASSEMBLY

DANGER

BEFORE OPENING ANY VIKING PUMP LIQUID CHAMBER (PUMPING CHAMBER, RESERVOIR, RELIEF VALVE ADJUSTING CAP FITTING ETC.) BE SURE:

1. THAT ANY PRESSURE IN CHAMBER HAS BEEN COMPLETELY VENTED THROUGH SUCTION OR DISCHARGE LINES OR OTHER APPROPRIATE OPENINGS OR CONNECTIONS.
2. THAT THE DRIVING MEANS (MOTOR, TURBINE, ENGINE, ETC.) HAS BEEN "LOCKED OUT" OR MADE NON-OPERATIONAL SO THAT IT CANNOT BE STARTED WHILE WORK IS BEING DONE ON PUMP.
3. THAT YOU KNOW WHAT LIQUID THE PUMP HAS BEEN HANDLING AND THE PRECAUTIONS NECESSARY TO SAFELY HANDLE THE LIQUID. OBTAIN A MATERIAL SAFETY DATA SHEET (MSDS) FOR THE LIQUID TO BE SURE THESE PRECAUTIONS ARE UNDERSTOOD.

FAILURE TO FOLLOW ABOVE LISTED PRECAUTIONARY MEASURES MAY RESULT IN SERIOUS INJURY OR DEATH.

Mark valve and head before disassembly to insure proper reassembly.

1. Remove valve cap.
2. Measure and record length of extension of adjusting screw. Refer to "A" on Figures 12, 13 and 14.
3. Loosen locknut and back out adjusting screw until spring pressure is released.
4. Remove bonnet, spring guide, spring and poppet from valve body. Clean and inspect all parts for wear or damage and replace as necessary.

ASSEMBLY

Reverse procedures outlined under Disassembly. If valve is removed for repairs, be sure to replace in same position. Relief valve adjusting screw cap must **always** point towards suction side of pump. If pump rotation is reversed, remove relief valve and turn end for end. Refer to Figures 1, 2, and 3, page 1.



TECHNICAL SERVICE MANUAL

ABRASIVE LIQUID HEAVY-DUTY BRACKET MOUNTED PUMPS

SERIES 4625

SIZES H-M

SECTION TSM 410.2

PAGE 9 OF 9

ISSUE B

ASSEMBLY

DANGER

BEFORE STARTING PUMP, BE SURE ALL DRIVE EQUIPMENT GUARDS ARE IN PLACE.

FAILURE TO PROPERLY MOUNT GUARDS MAY RESULT IN SERIOUS INJURY OR DEATH.

PRESSURE ADJUSTMENT

If a new spring is installed or if pressure setting of pressure relief valve is to be changed from that which the factory has set, the following instructions must be carefully followed.

1. Carefully remove valve cap which covers adjusting screw. Loosen locknut which locks adjusting screw so pressure setting will not change during operation of pump.
2. Install a pressure gauge in discharge line for actual adjustment operation.
3. Turn adjusting screw in to increase pressure and out to decrease pressure.
4. With discharge line closed at a point beyond pressure gauge, gauge will show maximum pressure valve will allow while pump is in operation.

IMPORTANT

In ordering parts for pressure relief valve, always give model number and serial number of pump as it appears on nameplate and name of part wanted. When ordering springs, be sure to give pressure setting desired.



WARRANTY

Viking warrants all products manufactured by it to be free from defects in workmanship or material for a period of one (1) year from date of startup, provided that in no event shall this warranty extend more than eighteen (18) months from the date of shipment from Viking. If, during said warranty period, any products sold by Viking prove to be defective in workmanship or material under normal use and service, and if such products are returned to Viking's factory at Cedar Falls, Iowa, transportation charges prepaid, and if the products are found by Viking to be defective in workmanship or material, they will be replaced or repaired free of charge, FOB: Cedar Falls, Iowa.

Viking assumes no liability for consequential damages of any kind and the purchaser by acceptance of delivery assumes all liability for the consequences of the use or misuse of Viking products by the purchaser, his employees or others. Viking will assume no field expense for service or parts unless authorized by it in advance.

Equipment and accessories purchased by Viking from outside sources which are incorporated into any Viking product are warranted only to the extent of and by the original manufacturer's warranty or guarantee, if any.

THIS IS VIKING'S SOLE WARRANTY AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, WHICH ARE HEREBY EXCLUDED, INCLUDING IN PARTICULAR ALL WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. No officer or employee of IDEX Corporation or Viking Pump, Inc. is authorized to alter this warranty.



VIKING PUMP INC. •
A Unit of IDEX Corporation

VIKING PUMP INC. •
Copyright 2000 •