



TECHNICAL SERVICE MANUAL

HEAVY-DUTY PUMPS
SERIES 4195 AND 495
SIZES GG - AL

SECTION TSM 144
PAGE 1 OF 10
ISSUE D

CONTENTS

Introduction	1
Safety Information.	2
Special Information	3
Special Mechanical Seals.	3
Maintenance	3
Disassembly	4
Assembly	7
Thrust Bearing Adjustment	8
Installation of Carbon Graphite Bushings.	8
Pressure Relief Valve Instructions	9

INTRODUCTION

The illustrations used in this manual are for identification purposes only and cannot be used for ordering parts. Obtain a parts list from the factory or a Viking® representative. Always give complete name of part, part number and material with model number and serial number of pump when ordering repair parts. The unmounted pump or pump unit model number and serial number are on the nameplate.

In the Viking model number system, basic size letters are combined with series number (4195 and 495) are used to indicate either an unmounted pump or mounted pump unit.

UNMOUNTED PUMP	UNITS
Foot Mounted	
GG4195	Units are designated by the unmounted pump model numbers followed by a letter(s) indicating drive style.
HJ4195	
HL4195	
AS4195	
AK4195	D = Direct Drive
AL4195	
Flange Mounted	
GG495	
HJ495	
HL495	M = Horizontal Direct Drive
AS495	
AK495	
AL495	

This manual deals only with Series 4195 and 495 Heavy Duty Pumps. Refer to Figures 1 through 14 for general configuration and nomenclature used in this manual. Pump specifications and recommendations are listed in Catalog Section 144, Series 4195 and 495 Heavy Duty Pumps.



FIGURE 1
GG, HJ and HL4195 SERIES
Foot Type Unmounted Pump with Tapped Ports



FIGURE 2
AS, AK and AL4195 SERIES
Foot Type Unmounted Pump with Tapped Ports



FIGURE 3
GG, HJ and HL495 SERIES
Unmounted Pump with Tapped Ports



FIGURE 4
AS, AK and AL495 SERIES
Unmounted Pump with Tapped Ports



SAFETY INFORMATION AND INSTRUCTIONS

IMPROPER INSTALLATION, OPERATION OR MAINTENANCE OF PUMP MAY CAUSE SERIOUS INJURY OR DEATH AND/OR RESULT IN DAMAGE TO PUMP AND/OR OTHER EQUIPMENT. VIKING'S WARRANTY DOES NOT COVER FAILURE DUE TO IMPROPER INSTALLATION, OPERATION OR MAINTENANCE.

THIS INFORMATION MUST BE FULLY READ BEFORE BEGINNING INSTALLATION, OPERATION OR MAINTENANCE OF PUMP AND MUST BE KEPT WITH PUMP. PUMP MUST BE INSTALLED, OPERATED AND MAINTAINED ONLY BY SUITABLY TRAINED AND QUALIFIED PERSONS.

THE FOLLOWING SAFETY INSTRUCTIONS MUST BE FOLLOWED AND ADHERED TO AT ALL TIMES.

Symbol
Legend :



Danger - Failure to follow the indicated instruction may result in serious injury or death.

WARNING

Warning - In addition to possible serious injury or death, failure to follow the indicated instruction may cause damage to pump and/or other equipment.



BEFORE opening any liquid chamber (pumping chamber, reservoir, relief valve adjusting cap fitting, etc.) be sure that :

- Any pressure in the chamber has been completely vented through the suction or discharge lines or other appropriate openings or connections.
- The pump drive system means (motor, turbine, engine, etc.) has been "locked out" or otherwise been made non-operational so that it cannot be started while work is being done on the pump.
- You know what material the pump has been handling, have obtained a material safety data sheet (MSDS) for the material, and understand and follow all precautions appropriate for the safe handling of the material.

WARNING

INSTALL pressure gauges/sensors next to the pump suction and discharge connections to monitor pressures.



WARNING

USE extreme caution when lifting the pump. Suitable lifting devices should be used when appropriate. Lifting eyes installed on the pump must be used **only** to lift the pump, **not** the pump with drive and/or base plate. If the pump is mounted on a base plate, the base plate must be used for all lifting purposes. If slings are used for lifting, they must be safely and securely attached. For weight of the pump alone (which does not include the drive and/or base plate) refer to the Viking Pump product catalog.



BEFORE operating the pump, be sure all drive guards are in place.



DO NOT attempt to dismantle a pressure relief valve that has not had the spring pressure relieved or is mounted on a pump that is operating.



DO NOT operate pump if the suction or discharge piping is not connected.



AVOID contact with hot areas of the pump and/or drive. Certain operating conditions, temperature control devices (jackets, heat-tracing, etc.), improper installation, improper operation, and improper maintenance can all cause high temperatures on the pump and/or drive.



DO NOT place fingers into the pumping chamber or its connection ports or into any part of the drive train if there is **any possibility** of the pump shafts being rotated.



WARNING

THE PUMP must be provided with pressure protection. This may be provided through a relief valve mounted directly on the pump, an in-line pressure relief valve, a torque limiting device, or a rupture disk. If pump rotation may be reversed during operation, pressure protection must be provided on **both** sides of pump. Relief valve adjusting screw caps must always point towards suction side of the pump. If pump rotation is reversed, position of the relief valve must be changed. Pressure relief valves cannot be used to control pump flow or regulate discharge pressure. For additional information, refer to Viking Pump's Technical Service Manual TSM 000 and Engineering Service Bulletin ESB-31.

WARNING

BEFORE operating the pump, be sure that:

- It is clean and free from debris
- all valves in the suction and discharge pipelines are fully opened.
- All piping connected to the pump is fully supported and correctly aligned with the pump.
- Pump rotation is correct for the desired direction of flow.



WARNING

THE PUMP must be installed in a manner that allows safe access for routine maintenance and for inspection during operation to check for leakage and monitor pump operation.

SPECIAL INFORMATION

DANGER !

Before opening any Viking pump liquid chamber (pumping chamber, reservoir, relief valve adjusting cap fitting, etc.) Be sure:

1. That any pressure in the chamber has been completely vented through the suction or discharge lines or other appropriate openings or connections.
2. That the driving means (motor, turbine, engine, etc.) has been "locked out" or made non-operational so that it cannot be started while work is being done on pump.
3. That you know what liquid the pump has been handling and the precautions necessary to safely handle the liquid. Obtain a material safety data sheet (MSDS) for the liquid to be sure these precautions are understood.

Failure to follow above listed precautionary measures may result in serious injury or death.

ROTATION: Viking pumps operate equally well in a clockwise or counterclockwise rotation. Shaft rotation determines which port is suction and which is discharge. Suction Port is where pumping elements (gear teeth) come out of mesh.

PRESSURE RELIEF VALVES:

1. Viking pumps are positive displacement pumps and must be provided with some sort of pressure protection. This may be a relief valve mounted directly on the pump, an inline pressure relief valve, a torque limiting device or a rupture disk.
2. There are relief valve options available on those pump models designed to accept a relief valve. Options may include a return to tank relief valve. Pumps equipped with a jacketed head plate are generally not available with a relief valve.
3. If pump rotation is reversed during operation, pressure protection must be provided on both sides of the pump.
4. The relief valve adjusting screw cap must always point towards the suction side of the pump. If pump rotation is reversed, remove the pressure relief valve and turn end for end. Refer to **Figure 5**.
5. Pressure relief valves should not be used to control flow or regulate discharge pressure.

For additional information on pressure relief valves, refer to **Technical Service Manual TSM 000** and **Engineering Service Bulletin ESB-31**.

SPECIAL MECHANICAL SEALS:

This bulletin illustrates the mechanical seal which is standard in the catalog pump. A Seal Installation Drawing will be furnished with a pump fitted with a non-standard mechanical seal. Consult this Seal Installation Drawing before disassembling pump.

Modifications are required to install PTFE mechanical seals in these pumps. Contact the factory for specific information.




FIGURE 5

MAINTENANCE

Series 4195 and 495 pumps are designed for long, trouble-free service life under a wide variety of application conditions with a minimum of maintenance. The points listed below will help provide long service life.

CLEANING PUMP: Keep the pump as clean as possible. This will facilitate inspection, adjustment and repair work and help prevent overlooking a dirt covered grease fitting.

STORAGE: If the pump is to be stored, or not used for six months or more, the pump must be drained and a light coat of non-detergent SAE 30 weight oil must be applied to all internal pump parts. Lubricate the fittings and apply grease to the pump shaft extension. Viking suggests rotating pump shaft by hand one complete revolution every 30 days to circulate the oil.

SUGGESTED REPAIR TOOLS: The following tools must be available to properly repair Series 4195 and 495 pumps. These tools are in addition to standard mechanics' tools such as open end wrenches, pliers, screw drivers, etc. Most of the items can be obtained from an industrial supply house.

1. Soft Headed hammer
2. Allen wrenches (set screws & special mechanical seals)
3. Snap Ring Pliers
INTERNAL – Viking Part No. 2-810-047-999
GG-HJ-HL 4195-495
EXTERNAL – Viking Part No. 2-810-029-375
GG-HJ-HL 4195-495
4. Mechanical Seal Installation Sleeve
2-751-001-730 for 0.75 inch seal; GG 4195-495
2-751-004-730 for 1.25 inch seal; AS-AL 4195-495
5. Bearing Locknut Spanner Wrench – 2-810-043-375
6. Spanner Wrench, adjustable pin type for use on bearing housing end cap. – 2-810-008-375
7. Brass bar
8. Arbor press
9. Standard 5/16" 12 point socket

DISASSEMBLY

DANGER !

Before opening any Viking pump liquid chamber (pumping chamber, reservoir, relief valve adjusting cap fitting, etc.) Be sure:

1. That any pressure in the chamber has been completely vented through the suction or discharge lines or other appropriate openings or connections.
2. That the driving means (motor, turbine, engine, etc.) has been "locked out" or made non-operational so that it cannot be started while work is being done on pump.
3. That you know what liquid the pump has been handling and the precautions necessary to safely handle the liquid. Obtain a material safety data sheet (MSDS) for the liquid to be sure these precautions are understood.

Failure to follow above listed precautionary measures may result in serious injury or death.

1. Refer to **Figures 7 & 8**, page 5 for model to be disassembled and name of parts. Models 4195 & 495 are disassembled and assembled in the same manner. The difference between these models is the casings.
2. Mark the head and casing before disassembly to insure proper reassembly.
3. **NOTE:** The four valve capscrews, valve and gasket must be removed from the GG4195-495 model before the six head capscrews are removed.
Remove the head capscrews.
4. Tilt the top of the head back when removing to prevent the idler from falling off the idler pin.
5. Remove the idler and bushing assembly. If the idler bushing needs replacing, see "**Installation of Carbon Graphite Bushings**," page 8.
6. Insert a brass bar or piece of hardwood in the port opening and between the rotor teeth to keep the shaft from turning. Turn the locknut counterclockwise and remove locknut. See **Figure 9 or 10**, page 6.
7. Loosen the two setscrews in the face of the bearing housing and turn the thrust bearing assembly counterclockwise and remove from casing. See **Figure 9 or 10**, page 6.
8. **GG, HJ, HL:** Remove the snap ring from the shaft. See **Figure 9**, page 6.
AS, AK, AL: Remove the bearing spacer from the shaft. See **Figure 10**, page 6.
9. Remove the brass bar or piece of hardwood from the port opening.




FIGURE 6
CUTAWAY FOR MODELS GG, HJ AND HL4195




FIGURE 7 - EXPLODED VIEW FOR MODELS GG, HJ AND HL 4195 AND 495

ITEM	NAME OF PART	ITEM	NAME OF PART	ITEM	NAME OF PART
1	Locknut	8	Casing (4195)	14	Head O-Ring
2	Snap Ring (Outer)	8A	Casing (495)	15	Idler Pin
3	Ball Bearing (Outer)	9	Pipe Plug	16	Head and Idler Pin Assembly
4	Snap Ring for Shaft *	10	Mechanical Seal	17	Capscrew for Head
5	Bearing Housing	11	Rotor and Shaft Assembly	18	Gasket for Relief Valve
6	Snap Ring (Inner)	12	Idler Bushing	19	Relief Valve
7	Ball Bearing (Inner)	13	Idler and Bushing Assembly	20	Capscrew for Valve

* Not used on "GG" size pumps.




FIGURE 8 - EXPLODED VIEW FOR MODELS AS, AK AND AL 4195 AND 495

ITEM	NAME OF PART	ITEM	NAME OF PART	ITEM	NAME OF PART
1	Locknut	9	Bearing Retainer Washer	16	Mechanical Seal
2	Bearing Spacer Collar	10	Casing (4195)	17	Idler Bushing
3	End Cap for Bearing Housing	10A	Casing (495)	18	Idler and Bushing Assembly
4	Lip Seal for Bearing Housing	11	O-Rings for Relief Valve	19	Head O-Ring
5	Ball Bearing (Outer)	12	Relief Valve	20	Idler Pin
6	Bearing Housing	13	Pipe Plug	21	Check Valve
7	Bearing Spacer	14	Capscrew for Valve	22	Head and Idler Pin Assembly
8	Ball Bearing (Inner)	15	Rotor and Shaft Assembly	23	Capscrew for Head




FIGURE 9 - THRUST BEARING ASSEMBLY GG, HJ AND HL SIZES




FIGURE 10 - THRUST BEARING ASSEMBLY AS, AK AND AL SIZES

10. The rotor and shaft can now be removed by tapping on the end of the shaft with a lead hammer or, if using a regular hammer, use a piece of hardwood between the shaft and hammer. The rotary member of the seal will come out with the rotor and shaft.
11. **AS, AK, AL:** Remove the bearing retainer washer. The washer may have stayed with the rotor and shaft when removed or is against the ball bearing. See **Figure 10**.
12. Remove the mechanical seal rotary member and spring from the rotor and shaft assembly.
13. **GG, HJ, HL:** Remove the inner snap ring and single row ball bearing from the casing.
14. Remove the seal seat or stationary part of the seal from the casing.
15. Disassemble the thrust bearing assembly.

GG, HJ, HL: Remove the outer snap ring from the bearing housing and remove the ball bearing. See **Figure 9**.

AS, AK, AL: Loosen the two setscrews in the flange outside diameter. Rotate the end cap and lip seal counterclockwise and remove. Remove the ball bearing. See **Figure 10**.

The casing should be examined for wear, particularly in the area between the ports. All parts should be checked for wear before the pump is put together.

When making major repairs, such as replacing a rotor and shaft; it is advisable to also install a new mechanical seal, head and idler pin, idler and bushing. See “**Installation of Carbon Graphite Bushings**,” page 8.

Clean all parts thoroughly and examine for wear or damage. Check the lip seals, ball bearings, bushing and idler pin and replace if necessary. Check all other parts for nicks, burrs, excessive wear and replace if necessary.

Wash the bearings in clean solvent. Blow out the bearings with compressed air. Do not allow the bearings to spin; turn them slowly by hand. Spinning the bearings will damage the race and balls. Make sure the bearings are clean, then lubricate with non-detergent SAE 30 weight oil and check for roughness. Roughness can be determined by turning the outer race by hand. Replace the bearings if they have roughness.

Be sure the shaft is free from nicks, burrs and foreign particles that might damage the mechanical seal. Scratches on the shaft in seal area will provide leakage paths under the mechanical seal. Use a fine emery cloth to remove scratches or sharp edges.

ASSEMBLY

Standard Mechanical Seal (Synthetic Rubber Bellows Type)

READ CAREFULLY BEFORE REASSEMBLING PUMP

The seal used in this pump is simple to install and good performance will result if care is taken during installation.

The principle of a mechanical seal is contact between the rotary and stationary members. These parts are lapped to a high finish and their sealing effectiveness depends on complete contact.

Prior to installing the rotary portion of the mechanical seal, prepare and organize the rotor shaft, head and idler assemblies and appropriate gaskets for quick assembly.

Once the rotary portion of the mechanical seal is installed on the rotor shaft, it is necessary to assemble the parts as quickly as possible to insure the seal does not stick to the shaft in the wrong axial position. The seal will stick to the shaft after several minutes setting time.

Never touch the sealing faces with anything except clean hands or clean cloth. Minute particles can scratch the seal faces and cause leakage.

1. Coat the idler pin with non-detergent SAE 30 weight oil and place idler and bushing on idler pin in the head. If replacing a carbon graphite bushing, refer to **"Installation of Carbon Graphite Bushings,"** page 8.
2. Clean the rotor hub and casing seal housing bore. Make sure both are free from dirt and grit. Coat the outer diameter of seal seat and inner diameter of seal housing bore with non-detergent SAE 30 weight oil.
3. Start the seal seat in the seal housing bore. If force is necessary protect the seal face with a clean cardboard disc and gently tap it in place with a piece of wood. Be sure the seal seat is completely seated in the bore.
4. Place a tapered installation sleeve on the shaft, refer to **Figure 11.** The sleeve is furnished with GG, AS, AK and AL replacement mechanical seals. Coat the rotor shaft, tapered installation sleeve and inner diameter of the mechanical seal rotary member with a generous amount of non-detergent SAE 30 weight oil. Petrolatum may be used but grease is not recommended.
5. Place the seal spring on the shaft against the rotor hub. Refer to **Figure 12.**




FIGURE 11




FIGURE 12

6. Slide the rotary member, lapped contact surface facing away from the spring, over installation sleeve on shaft until just contacting the spring. Do not compress the spring. Remove the installation sleeve.
7. Coat the rotor shaft with non-detergent SAE 30 weight oil. Install the rotor and shaft into the casing, slowly pushing until the ends of the rotor teeth are just below the face of the casing. Take care not to damage the seal seat.
8. Leave the rotor in this position. Withdrawal of the rotor and shaft may displace the carbon seal rotating face and result in damage to the seal.
9. Place the O-ring or gasket on the head and install the head and idler assembly on pump. The pump head and casing were marked before disassembly to insure proper reassembly. If not, be sure the idler pin, which is offset in the pump head, is positioned up and equal distance between port connections to allow for proper flow of liquid through the pump.
10. Tighten the head capscrews evenly.
11. If the pump was equipped with a relief valve and was removed during disassembly, install on the head with new O-Rings or gaskets. The relief valve adjusting screw cap must always point towards the suction port. Refer to **Figure 5,** page 3. For relief valve repair or adjustments, see **"Pressure Relief Valve Instructions,"** Page 9.
12. In 2005, the use of single seal bearings were phased out. Pumps now use "Sealed for Life" bearings that have seals on both sides. The new bearings can be installed either side first and do not need to be packed with grease. For older models with single seal bearings, pack the inner ball bearing with multi-purpose grease, NLGI #2.

GG, HJ, HL: Drive the bearing into the bore. Tap the inner race with a brass bar and lead hammer to position bearing. Install the inner snap ring.

AS, AK, AL: Install the bearing retainer washer over the shaft before installing the ball bearing. Install the ball bearing in the casing with sealed side towards head end of the pump. Drive the bearing into the bore. Tap the inner race with a brass bar and lead hammer to position the bearing.

13. GG, HJ, HL: Install the shaft snap ring in groove in the shaft. See **Figure 9**, page 6.

AS, AK, AL: Install the bearing spacer over the shaft and against the single row ball bearing. See **Figure 10**, page 6.

14. Pack the lubrication chamber between the inner ball bearing and double row ball bearing in the thrust bearing assembly approximately one-half full of multi-purpose grease, NLGI #2. The thrust bearing assembly will take the remaining space. See **Figure 9 and 10**, page 6.

15. Pack the double row ball bearing with multi-purpose grease, NLGI #2.

GG, HJ, HL: Install the ball bearing into the bearing housing with shield side toward the coupling end of the shaft. See **Figure 9**, page 6. Install the snap ring into bearing housing to retain ball bearing. This snap ring has a tapered edge to fit tapered groove in bearing housing. The tapered edge is located away from the ball bearing.

AS, AK, AL: Install the ball bearing into the bearing housing. Install the lip seal in the bearing housing end cap. The lip should face towards the end of the shaft. Put the bearing spacer collar in the lip seal and install in the bearing housing and tighten the set screws securely. See **Figure 10**, page 6.

16. Insert a brass bar or piece of hardwood through the port opening between the rotor teeth to keep the shaft from turning.

17. Start the thrust bearing assembly into casing. Turn by hand until tight. This forces the rotor against the head. Replace and tighten the locknut or shaft.

18. Remove the brass bar or hardwood from port opening.

19. Adjust pump end clearance, refer to "**Thrust Bearing Adjustment**".

THRUST BEARING ADJUSTMENT

See **Figures 9 and 10**.

Loosen the two screws in the face of the thrust bearing assembly.

If the shaft cannot be rotated freely, turn the thrust bearing assembly counterclockwise until the shaft can be turned easily.

To set end clearance:

1. While turning the rotor shaft, rotate the thrust bearing assembly clockwise until a noticeable drag occurs. This is zero end clearance.
2. Mark the position of the bearing housing with respect to the casing.
3. Rotate the thrust bearing assembly counterclockwise the distance listed below as measured on outside of bearing housing.
4. After the adjustment is made, tighten the two setscrews in the face of the bearing housing assembly to secure the position.

For viscosities above 2500 SSU, add additional end clearance (0.004" for GG, HJ and HL size pumps and 0.005" for AS, AK and AL size pumps).

PUMP SIZE	DISTANCE IN INCHES ON O.D. OF BEARING HOUSING	STANDARD END CLEARANCE
GG	0.44" (7/16")	.003
HJ , HL	0.56" (9/16")	.003
AS , AK , AL	0.5" (1/2")	.003

INSTALLATION OF CARBON GRAPHITE BUSHINGS

When installing the carbon graphite bushings, extreme care must be taken to prevent breaking. Carbon graphite is a brittle material and is easily cracked. If cracked, the bushing will quickly disintegrate. Using a lubricant and adding a chamfer on the bushing and the mating part will help in installation. The additional precautions listed below must be followed for proper installation:

1. A press must be used for installation.
2. Be certain the bushing is started straight.
3. Do not stop pressing the operation until the bushing is in the proper position, as starting and stopping may result in a cracked bushing.
4. Check the bushing for cracks after installation.

DANGER !

Before starting pump, be sure all drive equipment guards are in place.

Failure to properly mount guards may result in serious injury or death.

PRESSURE RELIEF VALVE INSTRUCTIONS




FIGURE 13
VALVE - GG, HJ and HL SIZES

VALVE - LIST OF PARTS

1. Valve Cap	6. Valve Body
2. Adjusting Screw	7. Valve Spring
3. Lock Nut	8. Poppet
4. Spring Guide	9. Cap Gasket
5. Bonnet	

DISASSEMBLY

DANGER !

Before opening any Viking pump liquid chamber (pumping chamber, reservoir, relief valve adjusting cap fitting, etc.) Be sure:

1. That any pressure in the chamber has been completely vented through the suction or discharge lines or other appropriate openings or connections.
2. That the driving means (motor, turbine, engine, etc.) has been "locked out" or made non-operational so that it cannot be started while work is being done on pump.
3. That you know what liquid the pump has been handling and the precautions necessary to safely handle the liquid. Obtain a material safety data sheet (MSDS) for the liquid to be sure these precautions are understood.

Failure to follow above listed precautionary measures may result in serious injury or death.




FIGURE 14
VALVE - AS, AK and AL SIZES

VALVE - LIST OF PARTS

1. Valve Cap	6. Valve Body
2. Adjusting Screw	7. Valve Spring
3. Lock Nut	8. Poppet
4. Spring Guide	9. Cap Gasket
5. Bonnet	10. Bonnet O-Ring

Mark the valve and head before disassembly to ensure proper reassembly.

1. Remove the valve cap.
2. Measure and record the length of extension of the adjusting screw. Refer to "A" on Figures 13 and 14.
3. Loosen the locknut and back out the adjusting screw until spring pressure is released.
4. Remove the bonnet, spring guide, spring and poppet from the valve body. Clean and inspect all parts for wear or damage and replace as necessary.

ASSEMBLY

Reverse the procedures outlined under "Disassembly." If the valve is removed for repairs, be sure to replace in the same position. The relief valve adjusting screw cap must always point towards suction side of the pump. If the pump rotation is reversed, remove the relief valve and turn end for end. Refer to Figure 5, page 3.



TECHNICAL SERVICE MANUAL

HEAVY-DUTY PUMPS
SERIES 4195 AND 495
SIZES GG - AL

SECTION	TSM 144
PAGE	10 OF 10
ISSUE	D

DANGER !

Before starting pump, be sure all drive equipment guards are in place.

Failure to properly mount guards may result in serious injury or death.

PRESSURE ADJUSTMENT

If a new spring is installed or if the pressure setting of the pressure relief valve is to be changed from that which the factory has set, the following instructions must be carefully followed.

1. Carefully remove the valve cap which covers the adjusting screw.
Loosen the locknut which locks the adjusting screw so the pressure setting will not change during operation of the pump.
2. Install a pressure gauge in the discharge line for actual adjustment operation.
3. Turn the adjusting screw in to increase the pressure and out to decrease the pressure.
4. With discharge line closed at a point beyond pressure gauge, the gauge will show the maximum pressure the valve will allow while the pump is in operation.

IMPORTANT

When ordering parts for the pressure relief valve, always give the model number and serial number of the pump as it appears on the nameplate and the name of the part wanted. When ordering springs, be sure to give the pressure setting desired.



WARRANTY

Viking warrants all products manufactured by it to be free from defects in workmanship or material for a period of one (1) year from date of startup, provided that in no event shall this warranty extend more than eighteen (18) months from the date of shipment from Viking. If, during said warranty period, any products sold by Viking prove to be defective in workmanship or material under normal use and service, and if such products are returned to Viking's factory at Cedar Falls, Iowa, transportation charges prepaid, and if the products are found by Viking to be defective in workmanship or material, they will be replaced or repaired free of charge, FOB. Cedar Falls, Iowa.

Viking assumes no liability for consequential damages of any kind and the purchaser by acceptance of delivery assumes all liability for the consequences of the use or misuse of Viking products by the purchaser, his employees or others. Viking will assume no field expense for service or parts unless authorized by it in advance.

Equipment and accessories purchased by Viking from outside sources which are incorporated into any Viking product are warranted only to the extent of and by the original manufacturer's warranty or guarantee, if any.

THIS IS VIKING'S SOLE WARRANTY AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, WHICH ARE HEREBY EXCLUDED, INCLUDING IN PARTICULAR ALL WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. No officer or employee of IDEX Corporation or Viking Pump, Inc. is authorized to alter this warranty.



CONTENTS

Introduction	1
Special Information	2
Special Mechanical Seals	2
Disassembly	3
Assembly	5
Thrust Bearing Adjustment	7
Installation of Carbon Graphite Bushings	7
Pressure Relief Valve Instructions	7

INTRODUCTION


The illustrations used in this manual are for identification purposes only and cannot be used for ordering parts. Obtain a parts list from the factory or a Viking® representative. Always give complete name of part, part number and material with model number and serial number of pump when ordering repair parts. The unmounted pump or pump unit model number and serial number are on the nameplate.

In the Viking model number system, basic size letters are combined with series number (4193 & 493) indicating both unmounted or mounted pump unit.


Model Number Chart

UNMOUNTED PUMP	UNITS
Foot Mounted	Units are designated by the unmounted pump model numbers followed by a letter(s) indicating drive style.
GG4193	
HJ4193	D-Direct Drive
HL4193	
AS4193	
AK4193	
AL4193	
Flange Mounted	
GG493	
HJ493	M-Horizontal Direct Drive
HL493	
AS493	
AK493	
AL493	IM-Vertical In-Line Direct Drive


This manual deals only with Series 4193 & 493 Heavy-Duty Pumps. Refer to figures 1thru 14 for general configuration & nomenclature used in the manual. Pump specifications and recommendations are listed in Catalog section 154, Series 4193 & 493 Heavy-Duty Pumps.




**FIGURE 1
GG, HJ & HL 4193 SERIES
Foot Type Unmounted Pump with Flanged Ports**



**FIGURE 2
AS, AK & AL 4193 SERIES
Foot Type Unmounted Pump with Flanged Ports**



**FIGURE 3
GG, HJ & HL 493 SERIES
Unmounted Pump with Flanged Ports**



**FIGURE 4
AS, AK & AL 493 SERIES
Unmounted Pump with Flanged Ports**

SPECIAL INFORMATION

DANGER

BEFORE OPENING ANY VIKING PUMP LIQUID CHAMBER (PUMPING CHAMBER, RESERVOIR, RELIEF VALVE ADJUSTING CAP FITTING ETC.) BE SURE:

1. THAT ANY PRESSURE IN CHAMBER HAS BEEN COMPLETELY VENTED THROUGH SUCTION OR DISCHARGE LINES OR OTHER APPROPRIATE OPENINGS OR CONNECTIONS.
2. THAT THE DRIVING MEANS (MOTOR, TURBINE, ENGINE, ETC.) HAS BEEN "LOCKED OUT" OR MADE NON-OPERATIONAL SO THAT IT CANNOT BE STARTED WHILE WORK IS BEING DONE ON PUMP.
3. THAT YOU KNOW WHAT LIQUID THE PUMP HAS BEEN HANDLING AND THE PRECAUTIONS NECESSARY TO SAFELY HANDLE THE LIQUID. OBTAIN A MATERIAL SAFETY DATA SHEET (MSDS) FOR THE LIQUID TO BE SURE THESE PRECAUTIONS ARE UNDERSTOOD.

FAILURE TO FOLLOW ABOVE LISTED PRECAUTIONARY MEASURES MAY RESULT IN SERIOUS INJURY OR DEATH.

ROTATION: Viking pumps operate equally well in a clockwise or counterclockwise rotation. Shaft rotation determines which port is suction and which is discharge. Port in area where pumping elements (gear teeth) come out of mesh is suction port.

PRESSURE RELIEF VALVES:

1. Viking pumps are positive placement pumps and must be provided with some sort of pressure protection. This may be a relief valve mounted directly on the pump, an inline pressure relief valve, a torque limiting device or a rupture disk.
2. There are relief valve options available on these pumps. Relief Valve options include an internal relief valve and a return to tank relief valve.
3. If pump rotation is to be reversed during operation, pressure protection must be provided on *both* sides of pump.
4. Relief valve adjusting screw cap must always point towards suction side of pump. If pump rotation is reversed, remove pressure relief valve and turn end for end.
5. Pressure relief valves cannot be used to control pump flow or regulate discharge pressure.

For additional information on pressure relief valves, refer to Technical Service Manual TSM000 and Engineering Service Bulletin ESB-31.




FIGURE 5

SPECIAL MECHANICAL SEALS

Extra care should be taken in repair of these pumps. Be sure to read and follow all special instructions supplied with your pump.

MAINTENANCE

Series 4193 & 493 pumps are designed for long, trouble free service life under a wide variety of application conditions with a minimum of maintenance. The points listed below will help provide long service.

CLEANING PUMP: Keep pump as clean as possible. This will facilitate inspection; adjustment and repair work and help prevent over looking a dirt covered grease fitting.

STORAGE: If pump is to be stored, or not used for six months or more, pump must be drained and a light coat of non-detergent SAE 30 weight oil must be applied to all internal pump parts. Lubricate fittings and apply grease to pump shaft extension.

Viking suggests rotating pump shaft by hand one complete revolution every 30 days to circulate oil.

SUGGESTED REPAIR TOOLS: The following tools must be available to properly repair Series 4193 and 4936 pumps. These tools are in addition to standard mechanics' tools such as, open end wrenches, pliers, screw drivers, etc. Most of the items can be obtained from an industrial supply house.

1. Soft Headed hammer
2. Allen wrenches (set screw & special mechanical seals)
3. Snap ring pliers
INTERNAL – Viking P/N 2-810-047-999
GG-HJ-HL 4193-493
EXTERNAL - Viking P/N 2-810-029-375
GG-HJ-HL 4193-493
4. Mechanical seal installation sleeve
2-751-001-900 for $\frac{3}{4}$ inch seal; GG-HJ-HL 4193-493
2-810-004-900 for $1\frac{1}{4}$ inch seal; AS-AL- 4193-493
5. Bearing locknut spanner wrench
Source: #471 J.H. Williams & Co. or equal)
6. Spanner wrench, adjustable pin type for use on bearing housing end cap
(Source: #482 J.H. Williams & Co. or equal)
7. Brass bar
8. Arbor press

DISASSEMBLY

DANGER

BEFORE OPENING ANY VIKING PUMP LIQUID CHAMBER (PUMPING CHAMBER, RESERVOIR, RELIEF VALVE ADJUSTING CAP FITTING ETC.) BE SURE:


1. THAT ANY PRESSURE IN CHAMBER HAS BEEN COMPLETELY VENTED THROUGH SUCTION OR DISCHARGE LINES OR OTHER APPROPRIATE OPENINGS OR CONNECTIONS.
2. THAT THE DRIVING MEANS (MOTOR, TURBINE, ENGINE, ETC.) HAS BEEN "LOCKED OUT" OR MADE NON-OPERATIONAL SO THAT IT CANNOT BE STARTED WHILE WORK IS BEING DONE ON PUMP.
3. THAT YOU KNOW WHAT LIQUID THE PUMP HAS BEEN HANDLING AND THE PRECAUTIONS NECESSARY TO SAFELY HANDLE THE LIQUID. OBTAIN A MATERIAL SAFETY DATA SHEET (MSDS) FOR THE LIQUID TO BE SURE THESE PRECAUTIONS ARE UNDERSTOOD.

FAILURE TO FOLLOW ABOVE LISTED PRECAUTIONARY MEASURES MAY RESULT IN SERIOUS INJURY OR DEATH.


1. Refer to figure 7 & 8 page 4 for model to be disassembled and name of parts. Models 4193 & 493 are disassembled and assembled the same. The difference between these models is the casing.
2. Mark head and casing before disassembly to ensure proper reassembly. The idler pin, which is offset in pump head, must be positioned toward and equal distance between port connections to allow for proper flow of liquid through the pump.
3. Remove the head capscrew.

NOTE: The four valve capscrews, valve and gasket must be removed from the GG 4193-493 models before the six head capscrews are removed.

4. Remove head from pump. Do not allow idler to fall from idler pin. Tilt top of head back when removing to prevent this. Avoid damaging head gasket.
5. Remove idler and bushing assembly. If idler bushing needs replacing, see "Installation of Graphite Bushings" page 7.
6. Remove locknut from shaft. See figure 9 or 10. A piece of brass or hardwood inserted in port opening and between rotor teeth will keep shaft from turning.
7. Loosen two setscrews in face of bearing housing and turn thrust bearing assembly counter clockwise and remove from casing. See figure 9 or 10.
8. Remove snap ring from shaft for GG, HJ, or HL size pumps, see figure 9.
9. Remove bearing spacer from shaft for AS, AK & AL size pumps, see figure 10.
10. Remove piece of brass or hardwood from port opening.




CUTAWAY OF MODELS GG, HJ or HL 4193
FIGURE 6




EXPLODED VIEW MODELS GG, HJ and HL 493 and 4193
FIGURE 7

ITEM	NAME OF PART	ITEM	NAME OF PART	ITEM	NAME OF PART	ITEM	NAME OF PART
1.	Locknut	7.	Ball Bearing	12.	Idler Bushing	18.	Gasket for Relief Valve
2.	Snap Ring, Outer	8.	Casing (4193)	13.	Idler and Bushing	19.	Relief Valve
3.	Ball Bearing, Outer	8A	Casing (493)	14.	Head Gasket	20.	Capscrew for Valve
4.	Snap Ring for Shaft	9.	Pipe Plug	15.	Idler Pin		
5.	Bearing Housing	10.	Mechanical Seal	16.	Head and Idler Pin		
6.	Snap Ring, Inner	11.	Rotor	17.	Capscrew for Head		




EXPLODED VIEW MODELS AS, AK and AL 493 and 4193
FIGURE 8

ITEM	NAME OF PART	ITEM	NAME OF PART	ITEM	NAME OF PART	ITEM	NAME OF PART
1.	Lockout	7.	Bearing Spacer	13.	Relief Valve	18.	Idler and Bushing
2.	Bearing Spacer Collar	8.	Ball Bearing Inner	14.	Pipe Plug	19.	Head Gasket
3.	End Cap of Bearing Housing	9.	Bearing Retainer Washer	15.	Capscrew for Valve	20.	Idler Pin
4.	Lip Seal for Bearing Housing	10.	Casing (4193)	16.	Rotor and Shaft	21.	Head and Idler Pin
5.	Ball Bearing, Outer	10A	Casing (493)	17.	Mechanical Seal	22.	Capscrew for Head
6.	Bearing Housing	11.	Gasket for Relief Valve	18.	Idler Bushing	23.	Capscrew for Valve



THRUST BEARING ASSEMBLY GG, HJ, HL SIZES
FIGURE 9



THRUST BEARING ASSEMBLY AS, AK, AL SIZES
FIGURE 10

11. The rotor shaft can now be removed by tapping on end of shaft with a lead hammer or, if using a regular hammer, use a piece of hardwood between shaft and hammer. The spring and rotary member of the seal will come out with rotor and shaft.
12. Remove inner snap ring and single row ball bearing from casing. See figure 9. The AS, AK & AL size pumps do not have this snap ring.
13. Remove bearing retainer washer from the AS, AK or AL size pumps. See figure 10.
14. Remove the seal seat or stationary part of seal from casing.
15. Disassemble thrust bearing assembly. Remove outer snap ring from bearing housing for GG, HJ or HL size pumps and ball bearing can be removed. See figure 9.
16. The AS, AK and AL thrust bearing assembly has an lip cap and end seal that can be removed after loosening two set screws in flange of bearing housing. Remove ball bearing. See figure 10.

The casing should be examined for wear, particularly in the area between ports. All parts should be checked for wear before pump is put together.

When making major repairs, such as replacing a rotor and shaft; it is advisable to also install a new mechanical seal, head and idler pin and bushing. See "Installation of Carbon Graphite Bushings" page 7.

Clean all parts thoroughly and examine for wear or damage. Check lip seals, ball bearings, bushing and idler pin and replace if necessary. Check all other parts for nicks, burrs, excessive wear and replace if necessary.

Wash bearings in clean solvent. Blow out bearings with compressed air. Do not allow bearings to spin; turn them slowly by hand. Spinning bearings will damage race and balls. Make sure bearings are clean, then lubricate with non-detergent SAE 30 weight oil and check for roughness. Roughness can be determined by turning outer race by hand. Replace bearings if bearings have roughness.

Be sure shaft is free from nicks, burrs and foreign particles that might damage mechanical seal. Scratches on shaft in seal area will provide leakage paths under mechanical seal.

ASSEMBLY

Standard Mechanical Seal (Synthetic Rubber Bellows Type)

The seal used in this pump simple to install and good performance will result if care is taken during installation.

The principle of mechanical seal is contact between the rotary and stationary members. These parts are lapped to a high finish and their sealing effectiveness depends on complete contact.

Prior to installing rotating portion of mechanical seal, prepare rotor shaft, head and idler assemblies and appropriate gaskets for quick assembly.

Once rotating pressure of mechanical seal is installed on rotor shaft, it is necessary to assemble parts as quickly as possible to ensure the seal does not stick to shaft in wrong axial position. The seal should be expected to stick to the shaft after several minutes setting time.

Never touch sealing faces with anything except clean hands or clean cloth. Minute particles can scratch the seal faces and cause leakage.

1. Coat idler pin with non-detergent SAE 30 weight oil and place idler and bushing in idler pin on head. If replacing a carbon graphite bushing, refer to installation of Carbon Graphite Bushings page 7.
2. Clean rotor, hub and casing seal housing bore. Make sure both are free from dirt and grit. Coat outer diameter of seal seat and inner diameter of seal housing bore with non-detergent SAE 30 weight oil.
3. Start seal seat in seal housing bore. If force is necessary, protect seal face with a clean cardboard disc and gently tap it in place with a piece of wood.




FIGURE 11




FIGURE 12

4. Place tapered installation sleeve on shaft, refer to figure 11. Sleeve is furnished with GG, AS, AK and AL size replacement mechanical seals. Coat rotor shaft, tapered installation sleeve and inner diameter of mechanical seal rotary member with a generous amount of non-detergent SAE 30 weight oil. Petrolatum may be used but grease is not recommended.
5. Place seal spring on shaft against rotor hub. Refer to figure 12.
6. Slide rotary member, lapped contact surface facing away from spring, over installation sleeve on shaft until it is against spring.
7. Do not compress spring.
8. Coat rotor shaft with non-detergent SAE 30 weight oil. Start end of shaft in bracket bushing and turn from right to left, slowly pushing until the ends of the rotor teeth are just below the face of the casing.
9. Leave the rotor in this position. Withdrawal of rotor and shaft may displace the carbon seal rotating face and result in damage to the seal.
10. Place O-ring gasket on head and install head and idler assembly on pump. Pump head and casing were marked before disassembly to insure proper reassembly. If not be sure idler pin, which is offset in pump head, is positioned toward or equal distance between port connections to allow for proper flow of liquid through pump.

11. Tighten head capscrews evenly.
12. If pump was equipped with a relief valve and was removed during disassembly, install on head with new gaskets. Relief valve adjusting screw cap must always point towards suction port. Refer to figure 5 page 2. For relief valve repair or adjustments, see PRESSURE RELIEF VALVE INSTRUCTIONS, page 7.
13. Pack ball bearing with multi-purpose grease, NLGI # 2, and install with casing with sealed side towards end of pump. Install inner snap ring in GG, HJ and HL size pumps. See figure 9.

NOTE: AS, AK and AL size pumps do not have a snap ring, a bearing retainer washer must be assembled over end of shaft before the bearing is assembled. See figure 10.

14. Place bearing spacer over shaft and against single row ball bearing in casing (AS, AK and AL size pumps). See figure 10. Install snap shaft ring in groove in the shaft (GG, HJ and HL size pump. See figure 8).
15. Pack lubrication chamber between inner ball bearing and double row ball bearing in the thrust bearing assembly approximately half full with multi-purpose grease, NLGI#2. See figures 9 and 10.
16. Pack double row ball bearing with multi-purpose grease, NLGI#2 and press into bearing housing with shield side toward coupling end of shaft. See Figure 9. (AS, AK and AL size pumps do not use a shielded bearing). Install snap ring to hold bearing in place on GG, HJ and HL size pumps.

NOTE: On AS, AK and AL size pumps, install lip seal in bearing house end cap. The lip should face towards end of shaft. Put bearing spacer sleeve in lip seal and install in bearing housing and tighten setscrews securely. See figure 20.

17. Insert a piece of brass or hard wood through port opening between rotor teeth to keep shaft from turning.
18. Start thrust bearing assembly into casing. Turn by hand until tight. This forces rotor against head. Replace and tighten locknut on shaft.
19. Remove brass piece or hardwood from port opening.

Adjust pump end clearance refer to page 7.

DANGER

BEFORE STARTING PUMP, BE SURE ALL DRIVE EQUIPMENT GUARDS ARE IN PLACE.

FAILURE TO PROPERLY MOUNT GUARDS MAY RESULT IN SERIOUS INJURY OR DEATH.

BEARING ADJUSTMENT THRUST

See figures 9 and 10.

Loosen two screws in face of thrust bearing assembly.

If shaft cannot be rotated freely, turn thrust bearing assembly counter clockwise until shaft cannot be turned easily.

To set end clearance:

1. While turning rotor shaft, rotate thrust bearing assembly clockwise until noticeable drag occurs (this is zero end clearance).
2. Mark position of bearing housing with respect to the casing.
3. Rotate thrust bearing assembly counter clockwise the distance listed below as measured on outside of bearing housing.
4. Tighten two setscrews in face of bearing housing after adjustment is made to secure thrust bearing assembly position.

For viscosities above 2500 SSU, add additional end clearance (.005" for GG, HJ and HL size pumps and .007" for AS, AK and AL size pumps).


PUMP SIZE	Distance in Inches on O.D. of Bearing Housing	END CLEARANCE
GG	11/16"	.005
HJ, HL	15/16"	.005
AS, AK, AL	11/4"	.008

INSTALLATION OF CARBON GRAPHITE BUSHINGS

When installing graphite bushings, extreme care must be taken to prevent breaking. Carbon graphite is a brittle material and easily cracked. If cracked the bushing will quickly disintegrate. Using a lubricant and adding a chamfer on the bushing and the mating part will help in installation. The additional precautions listed below must be followed for proper installation:

1. A press must be used for installation.
2. Be sure bushing is started straight.
3. Do not stop pressing operation until bushing is in proper position, starting and stopping will result in cracked bushing.
4. Check bushing for cracks after installation.


PRESSURE RELIEF VALVE INSTRUCTIONS



VALVE - GG, HJ and HL SIZE

LIST OF PARTS	
1. Valve Cap	6. Valve Body
2. Adjusting Screw	7. Valve Spring
3. Locknut	8. Poppet
4. Spring Guide	9. Cap Gasket
5. Bonnet	

FIGURE 13



VALVE - GG, HJ and HL SIZE

LIST OF PARTS	
1. Valve Cap	6. Valve Body
2. Adjusting Screw	7. Valve Spring
3. Locknut	8. Poppet
4. Spring Guide	9. Cap Gasket
5. Bonnet	10. Bonnet Gasket

FIGURE 14

DISASSEMBLY

Mark valve and head before disassembly to ensure proper reassembly.

1. Remove valve cap.
2. Measure a record length of extension of adjusting screw.
3. Refer to "A" on Figure 23.

DISASSEMBLY

DANGER

BEFORE OPENING ANY VIKING PUMP LIQUID CHAMBER (PUMPING CHAMBER, RESERVOIR, RELIEF VALVE ADJUSTING CAP FITTING ETC.) BE SURE:

1. THAT ANY PRESSURE IN CHAMBER HAS BEEN COMPLETELY VENTED THROUGH SUCTION OR DISCHARGE LINES OR OTHER APPROPRIATE OPENINGS OR CONNECTIONS.
2. THAT THE DRIVING MEANS (MOTOR, TURBINE, ENGINE, ETC.) HAS BEEN "LOCKED OUT" OR MADE NON- OPERATIONAL SO THAT IT CANNOT BE STARTED WHILE WORK IS BEING DONE ON PUMP.
3. THAT YOU KNOW WHAT LIQUID THE PUMP HAS BEEN HANDLING AND THE PRECAUTIONS NECESSARY TO SAFELY HANDLE THE LIQUID. OBTAIN A MATERIAL SAFETY DATA SHEET (MSDS) FOR THE LIQUID TO BE SURE THESE PRECAUTIONS ARE UNDERSTOOD.

FAILURE TO FOLLOW ABOVE LISTED PRECAUTIONARY MEASURES MAY RESULT IN SERIOUS INJURY OR DEATH.

Mark valve and head before disassembly to ensure proper reassembly.

1. Remove valve cap.
2. Measure a record length of extension of adjusting screw. Refer to "A" on Figure 23.
3. Loosen locknut and back out adjusting screw until spring pressure is being released.
4. Remove bonnet, spring guide, spring and poppet from valve body. Clean and inspect all parts for wear and damage and replace as necessary.

ASSEMBLY

Reserve procedures outlined under Disassembly. If valve is removed for repairs, be sure to replace in same position. Relief valve adjusting screw cap must always point towards suction valve of pump. If pump rotation is reserved, remove relief valve and turn end for end.

DANGER

BEFORE STARTING PUMP, BE SURE ALL DRIVE EQUIPMENT GUARDS ARE IN PLACE.

FAILURE TO PROPERLY MOUNT GUARDS MAY RESULT IN SERIOUS INJURY OR DEATH.

PRESSURE ADJUSTMENT

If a new spring is installed or if pressure setting of pressure relief valve is to be changed from that which the factory has set, the following instructions must be carefully followed.

1. Carefully remove valve cap, which covers adjusting screw.
2. Loosen locknut, which locks adjusting screw so pressure setting will not change during operation of pump.
3. Install pressure gauge in discharge line for actual adjustment operation.
4. Turn adjusting screw to increase pressure and out to decrease pressure.
5. With discharge line closed at a point beyond pressure gauge, gauge will show maximum pressure valve will allow while pump is in operation.

IMPORTANT

In ordering parts for pressure relief valve, always give model number and serial number of pump as it appears on nameplate and name of part wanted. When ordering springs, be sure to give pressure settings desired.



TECHNICAL SERVICE MANUAL

HEAVY-DUTY BRACKET MOUNTED PUMPS
SERIES 4193 & 493
SIZES GG - AL

SECTION TSM 154
PAGE 9 OF 9
ISSUE B



WARRANTY

Viking warrants all products manufactured by it to be free from defects in workmanship or material for a period of one (1) year from date of startup, provided that in no event shall this warranty extend more than eighteen (18) months from the date of shipment from Viking. If, during said warranty period, any products sold by Viking prove to be defective in workmanship or material under normal use and service, and if such products are returned to Viking's factory at Cedar Falls, Iowa, transportation charges prepaid, and if the products are found by Viking to be defective in workmanship or material, they will be replaced or repaired free of charge, FOB. Cedar Falls, Iowa.

Viking assumes no liability for consequential damages of any kind and the purchaser by acceptance of delivery assumes all liability for the consequences of the use or misuse of Viking products by the purchaser, his employees or others. Viking will assume no field expense for service or parts unless authorized by it in advance.

Equipment and accessories purchased by Viking from outside sources, which are incorporated into any Viking product, are warranted only to the extent of and by the original manufacturer's warranty or guarantee, if any.

THIS IS VIKING'S SOLE WARRANTY AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, WHICH ARE HEREBY EXCLUDED, INCLUDING IN PARTICULAR ALL WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

No officer or employee of IDEX Corporation or Viking Pump, Inc. is authorized to alter this warranty.



VIKING PUMP INC. •
A Unit of IDEX Corporation •

VIKING PUMP INC. •
Copyright© 2000 •

CONTENTS

Introduction	1
Special Information	1
Special Mechanical Seals	2
Disassembly	2
Assembly	5
Thrust Bearing Adjustment	7
Installation of Carbon Graphite Bushings	8
Pressure Relief Valve Instructions	8

INTRODUCTION

The illustrations in this manual are for identification purposes only and cannot be used for ordering parts. Obtain a parts list from the factory or a Viking® representative. Always give complete name of part, part number or material with model number and series number of pump when ordering repair parts. The unmounted pump or pump unit model number and serial number are on the nameplate.

In the Viking model number system, basic size letters are combined with series number (4197) indicating both unmounted or mounted pump unit.

Model Number Chart

UMOUNTED PUMPS	UNITS
Foot Mounted	Units are designated by the unmounted pump model numbers followed by a letter(s) indicating drive style.
GG4197	
HJ4197	
HL4197	
AS4197	
AK4197	
AL4197	

This manual deals only with Series 4197 Heavy-Duty Pumps. Refer to figures 1 thru 15 for general configuration and nomenclature used in this manual. Pump specifications and recommendations are listed in Catalogue Section 164, Series 4197 Stainless Steel Heavy-Duty Pumps.




FIGURE 1
GG, HJ and HL 4197 SERIES
Foot Type Unmounted Pump with Flanged Ports




FIGURE 2
AS, AK and AL 4197 SERIES
Foot Type Unmounted Pump with Flanged Ports

SPECIAL INFORMATION

DANGER

BEFORE OPENING ANY VIKING PUMP LIQUID CHAMBER (PUMPING CHAMBER, RESERVOIR, RELIEF VALVE ADJUSTING CAP FITTING ETC.) BE SURE:

1. THAT ANY PRESSURE IN CHAMBER HAS BEEN COMPLETELY VENTED THROUGH SUCTION OR DISCHARGE LINES OR OTHER APPROPRIATE OPENINGS OR CONNECTIONS.
2. THAT THE DRIVING MEANS (MOTOR, TURBINE, ENGINE, ETC.) HAS BEEN "LOCKED OUT" OR MADE NON-OPERATIONAL SO THAT IT CANNOT BE STARTED WHILE WORK IS BEING DONE ON PUMP.
3. THAT YOU KNOW WHAT LIQUID THE PUMP HAS BEEN HANDLING AND THE PRECAUTIONS NECESSARY TO SAFELY HANDLE THE LIQUID. OBTAIN A MATERIAL SAFETY DATA SHEET (MSDS) FOR THE LIQUID TO BE SURE THESE PRECAUTIONS ARE UNDERSTOOD.

FAILURE TO FOLLOW ABOVE LISTED PRECAUTIONARY MEASURES MAY RESULT IN SERIOUS INJURY OR DEATH.

ROTATION: Viking pumps operate equally well in a clockwise or counter clockwise rotation. Shaft rotation determines which port is suction and which is discharge. Port in area where pumping elements (gear teeth) come out of mesh is suction port.

PRESSURE RELIEF VALVES:

1. Viking pumps are positive placement pumps and must be provided with some sort of pressure protection. This may be a relief valve mounted directly on the pump, an inline pressure relief valve, a torque limiting device or a rupture disk.
2. There are relief valve options available on these pumps. Relief Valve options include an internal relief valve and a return to tank relief valve.
3. If pump rotation is to be reversed during operation, pressure protection must be provided on *both* sides of pump.
4. Relief valve adjusting screw cap must always point towards suction side of pump. If pump rotation is reversed, remove pressure relief valve and turn end for end.
5. Pressure relief valves cannot be used to control pump flow or regulate discharge pressure.

For additional information on pressure relief valves, refer to Technical Service Manual TSM000 and Engineering Service Bulletin ESB-31.

SPECIAL MECHANICAL SEALS

Extra care should be taken in repair of these pumps. Be sure to read and follow all special instructions supplied with your pump.




FIGURE 3

MAINTENANCE

Series 4197 pumps are designed for long, trouble free service life under a wide variety of application conditions with a minimum of maintenance. The points listed below will help provide long service.

CLEANING PUMP: Keep pump as clean as possible. This will facilitate inspection; adjustment and repair work and help prevent over looking a dirt covered grease fitting.

STORAGE: If pump is to be stored, or not used for six months or more, pump must be drained and a light coat of non-detergent SAE 30 weight oil must be applied to all internal pump parts. Lubricate fittings and apply grease to pump shaft extension.

Viking suggests rotating pump shaft by hand one complete revolution every 30 days to circulate oil.

SUGGESTED REPAIR TOOLS: The following tools must be available to properly repair Series 4197 pumps. These tools are in addition to standard mechanics' tools such as, open end wrenches, pliers, screw drivers, etc. Most of the items can be obtained from an industrial supply house.

1. Soft Headed Hammer
2. Allen wrenches (set screw & special mechanical seals)
3. Snap ring pliers
INTERNAL - Viking P/N 2-810-047-999 GG-HJ-HL 4197
EXTERNAL - Viking P/N 2-810-029-375 GG-HJ-HL 4197
4. Mechanical seal installation sleeve
2-751-001-900 for $\frac{3}{4}$ inch seal; GG-HJ-HL 4197
2-810-004-900 for $1\frac{1}{4}$ inch seal; AS-AL- 4197
5. Bearing locknut spanner wrench
Source: #471 J.H. Williams & Co. or equal)
6. Spanner wrench, adjustable pin type for use on bearing housing end cap
(Source: #482 J.H. Williams & Co. or equal)
7. Brass bar
8. Arbour press

DISASSEMBLY

DANGER

BEFORE OPENING ANY VIKING PUMP LIQUID CHAMBER (PUMPING CHAMBER, RESERVOIR, RELIEF VALVE ADJUSTING CAP FITTING ETC.) BE SURE:

1. THAT ANY PRESSURE IN CHAMBER HAS BEEN COMPLETELY VENTED THROUGH SUCTION OR DISCHARGE LINES OR OTHER APPROPRIATE OPENINGS OR CONNECTIONS.
2. THAT THE DRIVING MEANS (MOTOR, TURBINE, ENGINE, ETC.) HAS BEEN "LOCKED OUT" OR MADE NON-OPERATIONAL SO THAT IT CANNOT BE STARTED WHILE WORK IS BEING DONE ON PUMP.
3. THAT YOU KNOW WHAT LIQUID THE PUMP HAS BEEN HANDLING AND THE PRECAUTIONS NECESSARY TO SAFELY HANDLE THE LIQUID. OBTAIN A MATERIAL SAFETY DATA SHEET (MSDS) FOR THE LIQUID TO BE SURE THESE PRECAUTIONS ARE UNDERSTOOD.

FAILURE TO FOLLOW ABOVE LISTED PRECAUTIONARY MEASURES MAY RESULT IN SERIOUS INJURY OR DEATH.

1. Refer to figure 7 & 8 page 4 for model to be disassembled and name of parts.
2. Mark head and casing before disassembly to ensure proper reassembly. The idler pin, which is offset in pump head, must be positioned toward and equal distance between port connections to allow for proper flow of liquid through the pump.

3. Remove the head capscrew.

NOTE: The four valve capscrews, valve and gasket must be removed from the GG 4197 model before the six head capscrews are removed.

4. Remove head from pump. Do not allow idler to fall from idler pin. Tilt top of head back when removing to prevent this. Avoid damaging head gasket.

5. Remove idler and bushing assembly. If idler bushing needs replacing, see "Installation of Graphite Bushings" page 8.

6. Remove locknut from shaft. See figure 9 or 10. A piece of brass or hardwood inserted in port opening and between rotor teeth will keep shaft from turning.

7. Loosen two setscrews in face of bearing housing and turn thrust bearing assembly counter clockwise and remove from casing. See figure 9 or 10.

8. Remove snap ring from shaft for GG, HJ, or HL size pumps, see figure 9.

9. Remove bearing spacer from shaft for AS, AK & AL size pumps, see figure 9.

10. Remove piece of brass or hardwood from port opening.

11. The rotor shaft can now be removed by tapping on end of shaft with a lead hammer or, if using a regular hammer, use a piece of hardwood between shaft and hammer. The spring and rotary member of the seal will come out with rotor and shaft.

12. Remove inner snap ring and single row ball bearing from casing. See figure 9. The AS, AK & AL size pumps do not have this snap ring.

13. Remove bearing retainer washer from the AS, AK or AL size pumps. See figure 10.

14. With a drift or screwdriver inserted in the shaft end of casing, tap stationary seat from casing. See Figures 11 and 13.

15. Disassemble thrust-bearing assembly. Remove outer snap ring from bearing housing for GG, HJ or HL size pumps and ball bearing can be removed. See figure 9.

16. The AS, AK and AL thrust bearing assembly has an lip cap and end seal that can be removed after loosening two set screws in flange of bearing housing. Remove ball bearing. See figure 10.


The casing should be examined for wear, particularly in the area between ports. All parts should be checked for wear before pump is put together.

When making major repairs, such as replacing a rotor and shaft; it is advisable to also install a new mechanical seal, head and idler pin and bushing. See "Installation of Carbon Graphite Bushings" page 8.


Clean all parts thoroughly and examine for wear or damage. Check lip seals ball bearings, bushing and idler pin and replace if necessary. Check all other parts for nicks, burrs, excessive wear and replace if necessary.

Wash bearings in clean solvent. Blow out bearings with compressed air. Do not allow bearings to spin; turn them slowly by hand. Spinning bearings will damage race and balls. Make sure bearings are clean, then lubricate with non-detergent SAE 30-weight oil and check for roughness. Roughness can be determined by turning outer race by hand. Replace bearings if bearings have roughness.

Be sure shaft is free from nicks, burrs and foreign particles that might damage mechanical seal. Scratches on shaft in seal area will provide leakage paths under mechanical seal.




CUTAWAY OF MODELS GG, HJ or HL4197
FIGURE 4




EXPLODED VIEW MODELS GG, HJ and HL 4197
FIGURE 5

ITEM	NAME OF PART	ITEM	NAME OF PART	ITEM	NAME OF PART	ITEM	NAME OF PART
1.	Locknut	7.	Ball Bearing, Inner	13.	Idler and Bushing	19.	Relief Valve
2.	Snap Ring, Outer	8.	Casing	14.	Head Gasket	20.	Capscrew for Valve
3.	Ball Bearing, Outer	9.	Pipe Plug	15.	Idler Pin		
4.	Snap Ring for Shaft	10.	Mechanical Seal	16.	Head and Idler Pin		
5.	Bearing Housing	11.	Rotor and Shaft	17.	Capscrew for Head		
6.	Snap Ring, Inner	12.	Idler Bushing	18.	Gasket for Relief Valve		




EXPLODED VIEW MODELS AS, AK and AL 4197
FIGURE 6

ITEM	NAME OF PART	ITEM	NAME OF PART	ITEM	NAME OF PART	ITEM	NAME OF PART
1.	Lockout	7.	Bearing Spacer	13.	Pipe Plug	19.	Head Gasket
2.	Bearing Spacer Collar	8.	Ball Bearing Inner	14.	Capscrew for Valve	20.	Idler Pin
3.	End Cap of Bearing Housing	9.	Bearing Retainer Washer	15.	Rotor and Shaft	21.	Head and Idler Pin
4.	Lip Seal for Bearing Housing	10.	Casing	16.	Mechanical Seal	22.	Capscrew for Head
5.	Ball Bearing, Outer	11.	Gasket for Relief Valve	17.	Idler Bushing	23.	Pipe Plug
6.	Bearing Housing	12.	Relief Valve	18.	Idler and Bushing		



THRUST BEARING ASSEMBLY GG, HJ, HL SIZES
FIGURE 7



THRUST BEARING ASSEMBLY AS, AK, AL SIZES
FIGURE 8

ASSEMBLY

TEFLON FITTED MECHANICAL SEAL

1. Installing New Seal: See Figures 9 thru 13.

GENERAL INFORMATION:

Mechanical seals for HJ, HL, AS, AK and AL4197 size pumps are of the drive set screw type. Mechanical seals for GG4197 size pump are friction driven and are pressed onto rotor hub.

Installation sleeves are furnished with replacement seals for GG, AS, AK, size pumps. (this is not necessary with HJ and HL pumps). *NOTE: Cleanliness during installation is essential to seal performance. Never allow seal faces to contact a dirty surface.*

ORDER OF ASSEMBLY:

1. Stationary seat and seat ring in casing
2. Installation sleeve in shaft (where appropriate)
3. Seal rotating portion on rotor and shaft
4. Rotor and shaft into casing
5. Head with gasket and idler casing.

PREPARATION:

Remove burrs from threads and gently radius leading edges on rotor shaft. Use 300 grit paper to radius edges and to polish shaft at seal area. Clean rotor hub, shaft and seal seat

PREPARATION:

Remove burrs from threads and gently radius leading edges on rotor shaft. Use 300 grit paper to radius edges and to polish shaft at seal area. Clean rotor hub, shaft and seal seat bore in casing, making sure they are free from dirt and grit. Place installation sleeve on shaft, wide end against shaft shoulder. See figure 10.

STATIONARY SEAT ASSEMBLY:

Refer to Figures 9 and 11.

All models-Coat outside diameter of seat ring assembly and inside diameter of seal housing bore with SAE 30 oil. Align slot in back of seal seat with anti-rotation pin in bottom of casing seat bore and start seal seat into this bore. Protect lapped surface of seal seat with a disc of clean cardboard and press seal seat into this bore until it is firmly at the bottom of the bore. A hammer handle or wood dowel will serve to press against the cardboard disc and seat.

ASSEMBLY OF SEAL ROTATING PORTION:

Models HJ, HL, AS, AK and AL4197 (refer to figure 12) - Coat inside diameter of rotating portion assembly, shaft and tapered sleeve with SAE 30 weight oil. Be sure shaft is free of axial scratches, nicks and burrs. Check internal parts (Teflon rings and carbon washer) of rotating portion so that parts concentrically aligned so they will not be pinched and twisted at installation. With shaft pointed upward push rotating portion down along large shaft onto the large diameter. Remove holding clips, which hold spring-loaded disc away from Teflon and carbon parts. See figure 10. Push seal against rotor hub and tighten set screws to lock seal to shaft. Remove tapered sleeve.

MODEL GG4197 - rotating portion of the mechanical seal for GG4197 size pump does not have set screws to drive it and must depend upon interference fit with the rotor hub. See figure 12. The rotating portion must be disassembled before the retainer. (cartridge containing spring, disc, Teflon wedges and carbon face) can be pressed upon rotor hub. See figure 11.

To disassembly rotating portion of the seal compress carbon face and rapidly depress retaining ring through the notch at the end of the retainer cartridge, as shown in figure 15.

CAUTION

DO NOT ALLOW THE COMPRESSED SPRING TO BE RELEASED SUDDENLY, WHICH MIGHT SEND METAL PARTS FLYING, PROTECT YOUR EYES! PROTECT THE CARBON FACE AND THE TEFLON PARTS FROM DAMAGE OR CONTAMINATION. DISASSEMBLE THE SPRING AND DISC BY REMOVING THE HOLDING CLIPS AROUND THE OUTSIDE.

Press retainer cartridge onto other hub. See figure 12.

At the factory a tubular installation tube is inserted beside the retainer cartridge when pressing it onto the rotor hub. In lieu of a special tool, a 6 1/2" length of one-inch schedule 40 pipe or some blocks of wood and a light hammer can be used.


Lubricate rotor hub with Teflon paste, grease or SAE 30 oil and start retainer onto leading edge of rotor hub as evenly as possible.

Lubricate rotor hub with Teflon paste, grease or SAE 30 oil and start retainer onto leading edge of rotor hub as evenly as possible.

Insert one inch pipe into retainer cartridge and press it against the rotor hub, or, with a block of wood in each hand push on outside edge on side to force retainer down the hub. It may be necessary to use a length of hard wood and a light hammer to completely set retainer cartridge against back of the rotor of the rotor.

Check dimensionally from end of container to a machined portion on back of rotor at least two places 180° apart. Runout should not exceed 0.003" (the plane formed by the end of the retainer should be perpendicular to the shaft as closely as possible).

Clean up and blow out assembly just made. Replace spring and disc. Lubricate the two piece Teflon wedge inside and outside with SAE 30 oil. Place tapered sleeve furnished with replacement seals on shaft against largest shaft diameter and coat it with SAE 30 oil. Push Teflon wedge assembly over tapered sleeve and using carbon washer push wedge onto retainer against disc. Align retainer with carbon washer indents, compress and secure with retainer ring. When carbon face is compressed against spring some "drag" should be felt, but the spring must be able to push the wedge and carbon face out against the retainer ring.



MECHANICAL SEAL FOR
MODELS HJ, HL, AS, AK and AL4197

1. Retainer Cartrige
2. Springs
3. Wedge
4. Rotating face (washer)
5. Stationary Seat
6. Seat Ring (gasket)
7. Anti-rotation pin
8. Drive Set Screws

FIGURE 9

2. Remove installation sleeve.
3. All models - Flush sealing faces of both rotary member and seal seat with light oil and install rotor and shaft. Push rotor and shaft into casing slowly until ends of rotor teeth are just below the face of casing.

Place gasket on head and install head and idler assembly on pump. Pump head and casing were marked before disassembly to ensure proper reassembly. If not, be sure idler pin, which is offset in pump head, is positioned toward and equal distance between port connections to allow for proper flow of liquid through pump.

COAT SHAFT AND INSTALLATION SLEEVE
WITH LIGHT OIL BEFORE ASSEMBLY






FIGURE 10



MECHANICAL SEAL FOR GG4197

1. Retainer Cartrige
2. Springs
3. Wedge
4. Rotating face (washer)
5. Stationary Seat
6. Seat Ring (gasket)
7. Disc
8. Retaining Ring
9. Anti-rotation pin

FIGURE 11



GG4197 SEAL RETAINER CARTRIDGE ON ROTOR HUB
FIGURE 12

4. Tighten head capscrews evenly.
5. If pump was equipped with a relief valve and was removed during disassembly, install on head with new gaskets. Relief valve adjusting screw cap must always point towards suction pump. Refer to figure 3 page 2. For relief valve repair or adjustments, see PRESSURE RELIEF VALVE INSTRUCTIONS, page 8.
6. Pack ball bearing with multi-purpose grease, NLGI #2, and install in casing with sealed towards head end of pump. Install inner snap ring in GG, HJ and HL size pumps. See figure 7.

NOTE: AS, AK and AL size pumps do not have a snap ring, a bearing retainer washer must be assembled over end of shaft before the bearing is assembled. See figure 8.

7. Place bearing spacer over shaft and against single row ball bearing in casing (AS, AK and AL size pumps). See figure 8.
8. Install shaft snap ring in groove in the shaft (GG, HJ and HL size pumps). See figure 7.
9. Pack lubrication chamber between inner ball bearing and double row ball bearing in the thrust bearing assembly approximately half full with multi-purpose grease, NLGI #2. See figures 7 and 8.
10. Pack double row ball bearing with multi-purpose grease, NLGI #2 and press into bearing housing with shield side toward coupling end of shaft. See figure 7. (AS, AK and AL size pumps do not use a shielded bearing). Install snap ring to hold snap ring in place on GG, HJ and HL size pumps.

NOTE: On AS, AK and AL size pumps, install lip seal in bearing housing end of cap. The lip should face towards end of shaft. Put bearing spacer sleeve in lip seal and install in bearing housing and tighten set screws securely. See figure 8.

11. Insert a piece of brass hard wood through port opening between rotor teeth and keep shaft from turning.
12. Start thrust bearing assembly into casing. Turn by hand until tight. This forces rotor against head. Replace and tighten locknut on shaft.
13. Remove brass piece or hardwood from port opening
14. Adjust pump end clearance, refer to page 8.

DANGER

BEFORE STARTING PUMP, BE SURE ALL DRIVE EQUIPMENT GUARDS ARE IN PLACE.

FAILURE TO PROPERLY MOUNT GUARDS MAY RESULT IN SERIOUS INJURY OR DEATH.




FIGURE 13

THRUST BEARING ADJUSTMENT

See figures 7 and 8.

Loosen two screws in face of thrust bearing assembly.

If shaft cannot be rotated freely, turn thrust bearing assembly counter clockwise until shaft cannot be turned easily.

To set end clearance:

1. While turning rotor shaft, rotate thrust bearing assembly clockwise until noticeable drag occurs (this is zero end clearance).
2. Mark position of bearing housing with respect to the casing.
3. Rotate thrust bearing assembly counter clockwise the distance listed below as measured on outside of bearing housing.
4. Tighten two setscrews in face of bearing housing after adjustment is made to secure thrust bearing assembly position.

For viscosity's above 2500 SSU, add additional end clearance (.005" for GG, HJ and HL size pumps and .007" for AS, AK and AL size pumps).


PUMP SIZE	Distance in Inches on O.D. of Bearing Housing	END CLEARANCE
GG	11/16"	.005
HJ, HL	15/16"	.005
AS, AK, AL	11/4"	.008

INSTALLATION OF CARBON GRAPHITE BUSHINGS

When installing graphite bushings, extreme care must be taken to prevent breaking. Carbon graphite is a brittle material and easily cracked. If cracked the bushing will quickly disintegrate. Using a lubricant and adding a chamfer on the bushing and the mating part will help in installation. The additional precautions listed below must be followed for proper installation:

1. A press must be used for installation.
2. Be sure bushing is started straight.
3. Do not stop pressing operation until bushing is in proper position, starting and stopping will result in cracked bushing.
4. Check bushing for cracks after installation.

PRESSURE RELIEF VALVE INSTRUCTIONS



VALVE - GG, HJ, and HL SIZE
FIGURE 14

LIST OF PARTS

1. Valve Cap	6. Valve Body
2. Adjusting Screw	7. Valve Spring
3. Locknut	8. Poppet
4. Spring Guide	9. Cap Gasket
5. Bonnet	10. Bonnet Gasket

DANGER


BEFORE OPENING ANY VIKING PUMP LIQUID CHAMBER (PUMPING CHAMBER, RESERVOIR, RELIEF VALVE ADJUSTING CAP FITTING ETC.) BE SURE:

1. THAT ANY PRESSURE IN CHAMBER HAS BEEN COMPLETELY VENTED THROUGH SUCTION OR DISCHARGE LINES OR OTHER APPROPRIATE OPENINGS OR CONNECTIONS.
2. THAT THE DRIVING MEANS (MOTOR, TURBINE, ENGINE, ETC.) HAS BEEN "LOCKED OUT" OR MADE NON-OPERATIONAL SO THAT IT CANNOT BE STARTED WHILE WORK IS BEING DONE ON PUMP.
3. THAT YOU KNOW WHAT LIQUID THE PUMP HAS BEEN HANDLING AND THE PRECAUTIONS NECESSARY TO SAFELY HANDLE THE LIQUID. OBTAIN A MATERIAL SAFETY DATA SHEET (MSDS) FOR THE LIQUID TO BE SURE THESE PRECAUTIONS ARE UNDERSTOOD.

FAILURE TO FOLLOW ABOVE LISTED PRECAUTIONARY MEASURES MAY RESULT IN SERIOUS INJURY OR DEATH.

LIST OF PARTS

1. Valve Cap	6. Valve Cap
2. Adjusting Screw	7. Adjusting Screw
3. Locknut	8. Locknut
4. Spring Guide	9. Spring Guide
5. Bonnet	10. Bonnet



VALVE - AS, AK, and AL SIZE
FIGURE 15

Mark valve and head before disassembly to ensure proper reassembly.

1. Remove valve cap.
2. Measure a record length of extension of adjusting screw. Refer to "A" on Figure 14 and 15.
3. Loosen locknut and back out adjusting screw until spring pressure is being released.
4. Remove bonnet, spring guide, spring and poppet from valve body. Clean and inspect all parts for wear and damage and replace as necessary.



TECHNICAL SERVICE MANUAL

HEAVY-DUTY BRACKET MOUNTED PUMPS
SERIES 4197
SIZES GG - AL

SECTION TSM 164
PAGE 9 OF 9
ISSUE C

ASSEMBLY

Reserve procedures outlined under Disassembly. If valve is removed for repairs, be sure to replace in same position. Relief valve adjusting screw cap must always point towards suction valve of pump. If pump rotation is reversed, remove relief valve and turn end for end. Refer to figures 1 and 2 page 1.

DANGER

BEFORE STARTING PUMP, BE SURE ALL DRIVE EQUIPMENT GUARDS ARE IN PLACE.

FAILURE TO PROPERLY MOUNT GUARDS MAY RESULT IN SERIOUS INJURY OR DEATH.

PRESSURE ADJUSTMENT

If a new spring is installed or if pressure setting of pressure relief valve is to be changed from that which the factory has set, the following instructions must be carefully followed.

1. Carefully remove valve cap, which covers adjusting screw.
2. Loosen locknut, which locks adjusting screw so pressure setting will not change during operation of pump.
3. Install pressure gauge in discharge line for actual adjustment operation.
4. Turn adjusting screw to increase pressure and out to decrease pressure.
5. With discharge line closed at a point beyond pressure gauge, gauge will show maximum pressure valve will allow while pump is in operation.

IMPORTANT

In ordering parts for pressure relief valve, always give model number and serial number of pump as it appears on nameplate and name of part wanted. When ordering springs, be sure to give pressure settings desired.



WARRANTY

Viking warrants all products manufactured by it to be free from defects in workmanship or material for a period of one (1) year from date of startup, provided that in no event shall this warranty extend more than eighteen (18) months from the date of shipment from Viking. If, during said warranty period, any products sold by Viking prove to be defective in workmanship or material under normal use and service, and if such products are returned to Viking's factory at Cedar Falls, Iowa, transportation charges prepaid, and if the products are found by Viking to be defective in workmanship or material, they will be replaced or repaired free of charge, FOB. Cedar Falls, Iowa.

Viking assumes no liability for consequential damages of any kind and the purchaser by acceptance of delivery assumes all liability for the consequences of the use or misuse of Viking products by the purchaser, his employees or others. Viking will assume no field expense for service or parts unless authorized by it in advance.

Equipment and accessories purchased by Viking from outside sources, which are incorporated into any Viking product, are warranted only to the extent of and by the original manufacturer's warranty or guarantee, if any.

THIS IS VIKING'S SOLE WARRANTY AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, WHICH ARE HEREBY EXCLUDED, INCLUDING IN PARTICULAR ALL WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

No officer or employee of IDEX Corporation or Viking Pump, Inc. is authorized to alter this warranty.



VIKING PUMP INC. •
A Unit of IDEX Corporation •

VIKING PUMP INC. •
Copyright© 2000 •